VXIplug & play Diriver User'st Guide Silicon Agilem 1155B Semiconductor Parameter Analyzer Agilent 4156B Precision Semiconductor Parameter Analyzer 920-WWW.Siliconinvestig



Agilent Part No. 04156-90710 Printed in Japan May 2000

Edition 4

Legal Notice

The information contained in this document is subject to change without notice.

Copyright © 1997, 1998 Agilent Technologies

This document contains information which is protected by copyright. All rights are reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

• Product Warranty

Agilent Technologies warrant Agilent Technologies hardware, accessories and supplies against defects in materials and workmanship for the period of one year from the warranty start date specified below. If Agilent Technologies receive notice of such defects during the warranty period, Agilent Technologies will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or like-new.

Warranty service of this product will be performed at Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies do not warrant that the operation of Agilent Technologies products will be uninterrupted or error free. If Agilent is unable, within a reasonable time, to repair or replace any product to a condition as warranted, customer will be entitled to a refund of the purchase price upon prompt return of the product.

The Agilent Technologies products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use.

The warranty period begins on the date of delivery or on the date of installation if installed by Agilent Technologies. If customer schedules or delays Agilent Technologies installation more than 30 days after delivery, warranty begins on the 31st day from delivery.

Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by Agilent Technologies, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.

To the extent allowed by local law, the above warranties are exclusive and no other warranty or condition, whether written or oral, is expressed or implied and Agilent Technologies specifically disclaim any implied warranties or conditions of merchantability, satisfactory quality, and fitness for a particular purpose.

Agilent Technologies will be liable for damage to tangible property per incident up to the greater of \$300,000 or the actual amount paid for the product that is the subject of the claim, and for damages for bodily injury or death, to the extent that all such damages are determined by a court of competent jurisdiction to have been directly caused by a defective Agilent Technologies product.

To the extent allowed by local law, the remedies in this warranty statement are customer's sole and exclusive remedies. Expect as indicated above, in no event will Agilent Technologies or its suppliers be liable for loss of date or for direct, special, incidental, consequential (including lost profit or date), or other damage, whether based in contract, tort, or otherwise.

For consumer transactions in Australia and New Zealand: the warranty terms contained in this statement, except to the extent lawfully permitted, do not exclude, restrict or modify and are in addition to the mandatory statutory rights applicable to the sale of this product to you.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales Office.

Certification

Agilent Technologies Inc. certifies that this product met its published specifications at the time of shipment from the factory. Agilent further certifies that its calibration measurements are traceable to the National Institute of Standards and Technology (NIST), to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

Printing History

Edition 1:	August 1997
Edition 2:	July 1998
Edition 3:	January 2000
Edition 4:	May 2000

Microsoft, Windows, Windows NT, Visial Basic, and Visual C/C++ are registered trademarks of Microsoft Corporation.

Borland C/C++ Builder is registered trademark of International, Inc.

LabWindows and LabVIEW are registered trademarks of National Instruments Corporation.

Prober Control Software (PCS) is a product of Cascade Michrotech, Inc.

In This Manual

This manual provides information about VXI*plug&play* driver for Agilent 4155B/4156B. This manual also introduces two sample application programs using HP VEE and the VXI*plug&play* driver for the 4155B/4156B.

Installation

This chapter describes hardware and software requirements to use the 4155B/4156B VXI*plug&play* driver, and how to install the driver.

• Driver Functions

This chapter lists the all driver functions for the 4155B/4156B and Agilent E5250A Low Leakage Switch Mainframe.

• Programming Examples Using HP VEE

This chapter describes how to create measurement program using HP VEE, and provides programming examples.

• Sample Application Programs For HP VEE

This chapter provides how to install, execute, and modify the sample application programs stored in the VEE Sample Program Disk furnished with the 4155B/4156B.

1. Installation

Software Requirements	1-3
Hardware Requirements with HP VEE	1-4
Installing 4155B/4156B Driver	1-5
To Configure the Interface using HP I/O Library	1-6
To Install the Driver	1-7

2. Driver Functions

Driver Functions for the 4155B/4156B	2-3
hp4156b_abortMeasure	2-6
hp4156b_addSampleSyncIv	2-6
hp4156b_addSampleSyncPulse	2-7
hp4156b_addStressSyncIv	2-8
hp4156b_addStressSyncPulse	2-9
hp4156b_autoCal	2-9
hp4156b_clearSampleSync	2-10
hp4156b_clearStressSync	2-10
hp4156b_close	2-10
hp4156b_cmd	2-10
hp4156b_cmdData_Q	2-11
hp4156b_cmdInt	2-11
hp4156b_cmdInt16Arr_Q	2-12
hp4156b_cmdInt16_Q	2-12
hp4156b_cmdInt32Arr_Q	2-13
hp4156b_cmdInt32_Q	2-13
hp4156b_cmdReal	2-14
hp4156b_cmdReal64Arr_Q	2-14
hp4156b_cmdReal64_Q	2-15
hp4156b_cmdString_Q	2-15
hp4156b_dcl	2-15

hp4156b_error_message	. 2-16
hp4156b_error_query	. 2-16
hp4156b_errorQueryDetect	. 2-17
hp4156b_errorQueryDetect_Q	. 2-17
hp4156b_esr_Q	. 2-18
hp4156b_execCal	. 2-18
hp4156b_execOffsetCancel	. 2-19
hp4156b_force	. 2-20
hp4156b_forcePulse	. 2-21
hp4156b_init	. 2-22
hp4156b_measureM	. 2-23
hp4156b_measureP	. 2-24
hp4156b_offsetCancel	. 2-24
hp4156b_opc_Q	. 2-25
hp4156b_readData	. 2-25
hp4156b_readStatusByte_Q	. 2-26
hp4156b_recoverOutput.	. 2-26
hp4156b_reset	. 2-26
hp4156b_revision_query	. 2-27
hp4156b_sample	. 2-28
hp4156b_self_test	. 2-29
hp4156b_setFilter	. 2-30
hp4156b_setInteg	. 2-30
hp4156b_setIv	. 2-31
hp4156b_setPbias	. 2-32
hp4156b_setPguR	. 2-33
hp4156b_setPiv	. 2-34
hp4156b_setSample	. 2-35
hp4156b_setStress	. 2-35
hp4156b_setSweepSync.	. 2-36
hp4156b_setSwitch	. 2-37
hp4156b_setVm	. 2-37

1 = 415(h = = = +0.6 = = =
hp4156b_spotMeas2-3
hp4156b_startMeasure
hp4156b_stopMode2-4
hp4156b_stress
hp4156b_sweepIv2-4
hp4156b_sweepMiv
hp4156b_sweepPbias
hp4156b_sweepPiv2-4
hp4156b_timeOut2-4
hp4156b_timeOut_Q2-4
hp4156b_zeroOutput
Driver Functions for the E5250A 2-4
hne5250a hiasChanCard
hpe5250a_biasChanList 2-5
hpe5250a_biasChanList 0
hpe5250a_biasDort 2.5
hpe5250a_biasState 2.5
hpe5250a_blassiale
npe5250a_close
npe5250a_closeCard_Q2-5
hpe5250a_closeList
hpe5250a_closeList_Q2-5
hpe5250a_cmd
hpe5250a_cmdData_Q2-5
hpe5250a_cmdInt
hpe5250a_cmdInt16Arr_Q2-5
hpe5250a_cmdInt16_Q2-5
hpe5250a_cmdInt32Arr_Q2-5
hpe5250a_cmdInt32_Q2-5
hpe5250a_cmdReal2-5
hpe5250a_cmdReal64Arr_Q2-5
hpe5250a_cmdReal64_Q 2-6

3. Programming Examples Using HP VEE

Programming Basics	3-3
Registrating the Driver on HP VEE	3-4
Basic Objects to Control the Instrument	3-6

Debugging Your Program
Restrictions When Using the Driver with HP VEE
High-Speed Spot Measurements
Multi-Channel Spot Measurements
Staircase Sweep Measurements
Synchronous Sweep Measurements
Multi-Channel Sweep Measurements
Pulsed Spot Measurements
Multi-Channel Pulsed Spot Measurements
Pulsed Sweep Measurements
Multi-Channel Pulsed Sweep Measurements
Staircase Sweep with Pulsed Bias Measurements
Sampling Measurements
Stress Force

4. Sample Application Programs for HP VEE

Introduction 4-3 HP VEE Sample Program Disk 4-3 What are Sample Programs? 4-4
Installation
Using sample 1.vee
Panel Display 4-14 To Execute sample1.vee 4-15

Using sample2.vee	-19
Program Execution Flow 4-	-20
Panel Display	-22
To Execute sample2.vee	-23
Customizing Sample Programs 4-	-27
To Change an GPIB Address 4-	-28
To Change the Vth Measurement Setup 4-	-29
To Remove a Test Device 4-	-30
To Remove a Source Output 4-	-32
To Add a Test Device	-34
To Add a Measurement Parameter	-37

1 Installation

Installation

This chapter explains the environment requirements and installation of the VXIplug&play driver for Agilent 4155B/4156B. • "Software Requirements" "Hardware Requirements with HP VEE" • "Installing 4155B/4156B Driver" • NOTE The hardware required depends on the operating system and programming language used. This manual provides hardware requirements when using the driver with HP VEE software. When using the driver with a programming language other than HP VEE, refer to the appropriate programming manual.

Software Requirements

The following software is required to use the VXI*plug&play* driver for the 4155B/4156B. You can select one from Windows NT and Windows 95. You can also select the most comfortable programming language to develop and run programs.

- Operating System
 - Windows NT revision 3.51 or later
 - Windows 95
- 32-bit VISA I/O Library

I/O Library for GPIB Interface Card, or equivalent

- Programming Environment
 - HP VEE
 - Microsoft Visual Basic
 - Microsoft Visual C++
 - Borland C/C++
 - LabView
 - LabWindows
- VXIplug&play Driver Disk (furnished with the 4155B/4156B)
 - 4155B/4156B Plug&Play Driver Disk
 - E5250A Plug&Play Driver Disk

NOTE If you use the sample application programs, stored in the VEE Sample Program Disk furnished with the 4155B/4156B, HP VEE must be version 4.0 or later. See Chapter 4. Also, if you use the Cascade Microtech Summit series semi-auto prober, confirm the operating system supported by the prober control software (PCS) supplied from Cascade Microtech, Inc. PCS version 2.50 supports Windows 95 and Windows 3.1.

NOTE The E5250A Plug&Play Driver Disk stores the VXI*plug&play* driver for Agilent E5250A. This driver is required to use the sample application programs.

Hardware Requirements with HP VEE

The following hardware is required to use HP VEE and the VXIplug&play drivers.

- Controller
 - 486/66 with Coprocessor (minimum recommendation)
 - 586(Pentium)/90 or better is recommended.
- Memory
 - For Windows 95: 16 Mbyte. 24 Mbyte or more is recommended.
 - For Windows NT: 24 Mbyte. 32 Mbyte or more is recommended.
- Hard disk (minimum disk space)
 - 20 Mbytes for HP VEE version 4.0
 - 2 Mbytes for 4155B/4156B driver
 - 1 Mbyte for E5250A driver
- Graphics

 $1024 \times 768.\ 1280 \times 1024$ is recommended.

• IEEE 488 Interface card

Agilent 82341C GPIB Interface Card, or equivalent.

• CD-ROM drive

A CD-ROM drive will be required to install the software needed to use the VXI*plug&play* driver.

• Flexible disk drive

A 3.5 inch flexible disk drive is required to install the drivers.

Installing 4155B/4156B Driver

The installation flow for the VXI*plug&play* driver is shown below. If you have already installed the IEEE 488 interface card, VISA I/O library, and programming software on your PC, skip steps 1 through 4.

1. Install the IEEE 488 interface card into your PC.

See the interface card manual. Note the model number of the interface card, as you may need it to configure the interface (in step 3).

2. Install VISA I/O library.

Follow the instructions in the I/O library's setup program.

3. Configure and check the IEEE 488 interface.

See the I/O library manual. If you use the HP I/O Library, also see "To Configure the Interface using HP I/O Library" on page 1-6.

4. Install the programming software.

Follow the setup program instructions.

5. Install the VXI*plug&play* driver.

See "To Install the Driver" on page 1-7.

6. Register the driver in the programming software.

See the programming software manual. If you are using HP VEE, also see "Programming Basics" in Chapter 3.

Installation Installing 4155B/4156B Driver

To Configure the Interface using HP I/O Library

After installing the IEEE 488 interface card and the HP I/O Library, configure the interface. The procedure shown below is the easiest way to configure the interface. First, execute I_O Config in the HP I_O Libraries folder. The I/O Config window is displayed. See Figure 1-1.

1. Click Auto Add.

If the interface card is installed properly, I_O Config automatically detects the hardware configuration. The default names for SICL and VISA are assigned and listed, as shown in the Configured Interface list.

- 2. Click hpib7 GPIB0.
- 3. Click Edit to display the Configuration dialog box for the interface card.

If you find any conflicts in the dialog box, such as IRQ line, you may need to change them manually. Normally you can exit without modifying the default setup.

4. Click OK to exit. Reboot your PC to configure the interface.

Figure 1-1 To Configure the Interface using HP I/O Library

🔛 Interface Configuration Application - 1/0 Config 📃 🔲 🗙	
<u>File</u> <u>Options</u> <u>H</u> elp	HP 82340/82341 Configuration
This utility configures I/D interfaces. It must be run whenever a new I/D interface is installed in the computer or when changes need to be made to an existing I/D interface.	Questions? Press the Help button below. Recommended default values are shown.
To configure a new interface, select it in the Available Interface Types list and click on Configure. To edit a previously configured interface, select it in the Configured Interfaces list and click on Edit.	
Available Interface Types Configured Interfaces	Base Address: 0x250 0K 4
HP 82335 HP-IB CDM1 ASRL1 Auto Add 1 HP 823008831 HP-IB CDM1 ASRL2 Auto Add 1 HP 823008831 HP-IB CDM2 ASRL2 Auto Add 2	SICL Interface Name: Troby
LAN Server OK	VISA Interface Name: GPIB0 + Help
RS-322 VISA LAN Client VXI Command Module Help 3	Logical Unit: 7
	IRQ Line: 11
Configure Edt Remove	Bus Address: 21 - Edit VISA Config
	System Controller

NOTE

VISA Name is used by the VXIplug&play drivers to access the interface.

To Install the Driver

- 1. Insert the 4155B/4156B Plug&Play Driver Disk into the flexible disk drive connected to your PC.
- 2. Execute the 4156B.EXE program stored on the diskette. The program automatically installs the driver in the following directory.
 - For Windows NT: \Vxipnp\Winnt\Hp4156b
 - For Windows 95: \Vxipnp\Win95\Hp4156b

Following files are installed in the directory.

- hp4156b.bas
- hp4156b.c
- hp4156b.def
- hp4156b.fp
- hp4156b.GID
- hp4156b.h
- hp4156b.hlp
- readme.txt
- DelsL1.isu
- 3. If you are also installing the driver for the E5250A, do the following.
 - a. Insert the E5250A Plug&Play Driver Disk into the flexible disk drive connected to your PC.
 - b. Execute the E5250A.EXE program stored on the diskette. The program automatically installs the driver in the following directory.
 - For Windows NT: \Vxipnp\Winnt\Hpe5250a
 - For Windows 95: \Vxipnp\Win95\Hpe5250a

Following files are installed in the directory.

- hpe5250a.bas
- hpe5250a.c
- hpe5250a.def
- hpe5250a.fp
- hpe5250a.GID
- hpe5250a.h
- hpe5250a.hlp
- readme.txt
- DelsL1.isu

Installation Installing 4155B/4156B Driver

2 Driver Functions

This section explains all the driver finctions available for Agilent 41555B/4156B and Agilent E5250A.

- "Driver Functions for the 4155B/4156B"
- "Driver Functions for the E5250A"
- **NOTE** For additional information on each function. refer to the on-line help for the VXI*plug&play* drivers, or open the hp4156b.hlp or hpe5250a.hlp file in the direcroty the driver is installed. See "Installing 4155B/4156B Driver" in Chpater 1.

Driver Functions for the 4155B/4156B

Table 2-1 lists all the functions for the 4155B/4156B. You will see a brief description of the functions in the table.

For the description, syntax and parameters of the function, refer to the reference section following this table. The driver functions in the reference section will appear in the alphabetical order.

Category	Function	Description
Miscellaneous	hp4156b_init	Initializes the 4155B/4156B.
	hp4156b_close	Closes the connection with the 4155B/4156B.
	hp4156b_reset	Executes the 4155B/4156B reset.
	hp4156b_self_test	Executes the 4155B/4156B self-test.
	hp4156b_error_query	Queries the 4155B/4156B for error code/message.
	hp4155b_error_message	Queries for the driver errors.
	hp4156b_revision_query	Queries for the 4155B/4156B firmware/driver revisions.
	hp4156b_timeOut	Sets the timeout.
	hp4156b_timeOut_Q	Queries for the timeout setting.
	hp4156b_errorQueryDetect	Sets the automatic error checking.
	hp4156b_errorQueryDetect_Q	Queries for the automatic error checking setting.
	hp4156b_dcl	Sends the Device Clear.
	hp4156b_esr_Q	Queries the ESR status.
	hp4156b_readStatusByte_Q	Reads the 4155B/4156B status byte.
	hp4156b_opc_Q	Checks the 4155B/4156B operation completion status.
Primitive	hp4156b_startMeasure	Starts a measurement.
Measurement	hp4156b_readData	Reads a measurement result.
Functions	hp4156b_stopMode	Sets the measurement completion mode.
	hp4156b_abortMeasure	Aborts output or measurement.
Calibration	hp4156b_autoCal	Sets the auto calibration mode
	hp4156b_execCal	Executes the 4155B/4156B calibration
Zero Offset	hp4156b_offsetCancel	Sets the zero offset cancel.
Cancel	hp4156b_execOffsetCancel	Executes the zero offset cancel.

Category	Function	Description
Measurement	hp4156b_setSwitch	Sets the output switch.
Unit Setup	hp4156b_setFilter	Sets the output filter.
	hp4156b_setInteg	Sets the integration time.
	hp4156b_setVm	Sets the VMU measurement mode.
	hp4156b_setPguR	Sets the PGU output impedance.
Source Setup	hp4156b_force	Applies a dc current or voltage.
	hp4156b_forcePulse	Applies a pulse by using PGU.
	hp4156b_zeroOutput	Disables output.
	hp4156b_recoverOutput	Recovers output.
	hp4156b_setIv	Sets the sweep source.
	hp4156b_setPbias	Sets the pulsed bias source.
	hp4156b_setPiv	Sets the pulsed sweep source.
	hp4156b_setSweepSync	Sets the synchronous sweep source.
Measurement	hp4156b_spotMeas	Executes a high speed spot measurement.
Execution	hp4156b_measureM	Executes a multi-channel spot measurement.
	hp4156b_sweepIv	Executes a one channel sweep measurement.
	hp4156b_sweepMiv	Executes a multi-channel sweep measurement.
	hp4156b_measureP	Executes a pulsed spot measurement.
	hp4156b_sweepPiv	Executes a pulsed sweep measurement.
	hp4156b_sweepPbias	Executes a sweep measurement with pulsed bias.
Sampling	hp4156b_setSample	Sets the timing parameters.
Measurements	hp4156b_addSampleSynclv	Sets the dc source.
	hp4156b_addSampleSyncPulse	Sets the pulse source.
	hp4156b_sample	Executes a sampling measurement.
	hp4156b_clearSampleSync	Clears the source setup.
Stress Force	hp4156b_setStress	Sets the timing parameters.
	hp4156b_addStressSyncIv	Sets the dc stress source.
	hp4156b_addStressSyncPulse	Sets the pulse stress source.
	hp4156b_stress	Forces stress.
	hp4156b_clearStressSync	Clears the source setup.

Category	Function	Description
Passthrough	hp4156b_cmd	Sends a command.
Functions	h4156b_cmdInt	Sends a command with an integer parameter.
	hp4156b_cmdReal	Sends a command with a real parameter.
	hp4156b_cmdData_Q	Sends a command to read any data.
	hp4156b_cmdString_Q	Sends a command to read string response.
	hp4156b_cmdInt16_Q	Sends a command to read 16 bit integer response.
	hp4156b_cmdInt16Arr_Q	Sends a command to read 16 bit integer array response.
	hp4156b_cmdInt32_Q	Sends a command to read 32 bit integer response.
	hp4156b_cmdInt32Arr_Q	Sends a command to read 32 bit integer array response.
	hp4156b_cmdReal64_Q	Sends a command to read 64 bit real response.
	hp4156b_cmdReal64Arr_Q	Sends a command to read 64 bit real array response.

Driver Functions hp4156b_abortMeasure

hp4156b_abortMeasure

This function aborts the 4155B/4156B's present operation, such as the measurement executed by the hp4156b startMeasure function, the pulse output by the hp4156b forcePulse function, the stress force by the hp4156b stress function, and so on. Syntax ViStatus VI FUNC hp4156b abortMeasure(ViSession vi); **Parameters** vi Instrument handle returned from hp4156b init(). hp4156b addSampleSyncIv This function specifies the constant current source or constant voltage source used for the sampling measurements, and sets the parameters. Source output starts at the beginning of the sampling measurement (beginning of the hold time), and stops at the end of the last sampling measurement point. Sampling measurement channels are defined by the hp4156b sample function, and sampling measurement timing is defined by the hp4156b setSample function. Syntax ViStatus VI FUNC hp4156b addSampleSyncIv(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViReal64 base, ViReal64 bias, ViReal64 comp); **Parameters** vi Instrument handle returned from hp4156b init(). channel Channel number of the source unit. 1 to 6 (SMU1 to SMU6), 21 (VSU1), 22 (VSU2), 27 (PGU1), or 28 (PGU2) mode Output mode. 1 (current output, only for SMU) or 2 (voltage output). Output range. 0 (auto ranging) or positive value (limited auto range ranging). See below. For current output: 1E-11 to 1.0 A, or 0. For voltage output: 2.0 to 200.0 V, or 0. base Base value. -1.0 to 1.0 A for current output, -200.0 V to 200.0 V for voltage output. bias Bias value. -1.0 to 1.0 A for current output, -200.0 V to 200.0 V for voltage output. Compliance value. -200.0 V to 200.0 V for voltage compliance, comp -1.0 to 1.0 A for current compliance.

hp4156b_addSampleSyncPulse

	This function specifies the pulse source (PGU) used for the sampling measurements, and sets the parameters. Pulse outputs start at the beginning of the sampling measurement (beginning of the hold time), and stop at the end of the last sampling measurement point or stop at the last pulse if it comes earlier than the last sampling measurement point.		
	Sampling measurement channels are defined by the hp4156b_sample function, and sampling measurement timing is defined by the hp4156b_setSample function.		
If you want to let the pulse output synchronize with the sample timing, you should define carefully both the hp4156b_addSam parameters (count, period, width, delay, rise and fall) and the h timing parameters.		e pulse output synchronize with the sampling measurement define carefully both the hp4156b_addSampleSyncPulse timing period, width, delay, rise and fall) and the hp4156b_setSample	
Syntax	ViStatus _VI_FUNC hp4156b_addSampleSyncPulse(ViSession vi, ViInt32 channel, ViReal64 base, ViReal64 peak, ViInt32 count, ViReal64 period, ViReal64 width, ViReal64 delay, ViReal64 rise, ViReal64 fall);		
Parameters	vi	Instrument handle returned from hp4156b_init().	
	channel	Channel number of the pulse generator unit.	
		27 (PGU1) or 28 (PGU2)	
	base	Pulse base value40.0 to 40.0 V.	
	peak	Pulse peak value40.0 to 40.0 V.	
	count	Pulse count (number of pulses). 1 to 65535, or 0 (free run mode).	
	period	Pulse period. 1E-6 to 10.0 seconds.	
	width	Pulse width. 1E-6 to 9.99 seconds.	
	delay	Pulse delay time. 0.0 to 10.0 seconds.	
	rise	Pulse leading time. 0.1E-6 to 10E-3 seconds.	
	fall	Pulse trailling time. 0.1E-6 to 10E-3 seconds.	

Driver Functions hp4156b_addStressSynclv

hp4156b_addStressSyncIv

This function specifies the DC stress source, and sets the parameters. You can use maximum 4 stress sources at once by using the hp4156b_addStressSyncIv and/or hp4156b_addStressSyncPulse functions.

Syntax ViStatus _VI_FUNC hp4156b_addStressSyncIv(ViSession vi, ViInt32 source, ViInt32 channel, ViInt32 mode, ViReal64 range, ViReal64 base, ViReal64 stress, ViReal64 comp);

vi	Instrument handle returned from hp4156b_init().		
source	Reference number of the stress source. 1, 2, 3, or 4.		
channel	Channel number of the stress source.		
	1 to 6 (SMU1 to SMU6), 21 (VSU1), 22 (VSU2), 27 (PGU1), or 28 (PGU2)		
mode	Output mode. 1 (current output, only for SMU) or 2 (voltage output).		
range	Output range. 0 (auto ranging) or positive value (limited auto ranging). See below.		
	For current output: 1E-11 to 1.0 A, or 0.		
	For voltage output: 2.0 to 200.0 V, or 0.		
base	Base value1.0 to 1.0 A for current output, -200.0 V to 200.0 V for voltage output.		
stress	Stress value1.0 to 1.0 A for current output, -200.0 V to 200.0 V for voltage output.		
comp	Compliance value200.0 V to 200.0 V for voltage compliance, -1.0 to 1.0 A for current compliance.		

Parameters

hp4156b_addStressSyncPulse

	This function can use maxin and/or hp4150 for the setting	specifies the pulse stress source (PGU), and sets the parameters. You num 4 stress sources at once by using the hp4156b_addStressSyncIv 6b_addStressSyncPulse functions. See "hp4156b_stress" on page 41 g of width and delay.	
Syntax	ViStatus _VI_FUNC hp4156b_addStressSyncPulse(ViSession vi, ViInt32 source, ViInt32 channel, ViReal64 base, ViReal64 stress, ViReal64 width, ViReal64 delay, ViReal64 rise, ViReal64 fall);		
Parameters	vi	Instrument handle returned from hp4156b_init().	
	source	Reference number of the stress source. 1, 2, 3, or 4.	
	channel	Channel number of the pulse generator unit.	
		27 (PGU1) or 28 (PGU2)	
	base	Stress pulse base value40.0 to 40.0 V.	
	stress	Stress pulse peak value40.0 to 40.0 V.	
	width	Pulse width. 1E-6 to 9.99 seconds.	
	delay	Pulse delay time. 0.0 to 10.0 seconds.	
	rise	Pulse leading time. 0.1E-6 to 10E-3 seconds.	
	fall	Pulse trailling time. 0.1E-6 to 10E-3 seconds.	
	hp4156b_autoCal		
	This function enables or disables the auto calibration function.		
Syntax	ViStatus _VI_	ViStatus _VI_FUNC hp4156b_autoCal(ViSession vi, ViInt32 state);	
Parameters	vi	Instrument handle returned from hp4156b_init().	
	state	Auto calibration mode. 0 (OFF) or 1 (ON).	

Driver Functions hp4156b_clearSampleSync

hp4156b_clearSampleSync

	This function clears the settings of the constant voltage/current source defined by the hp4156b_addSampleSyncIv function, and the settings of the pulse source defined by the hp4156b_addSampleSyncPulse function.		
Syntax	ViStatus _VI_FUN	IC hp4156b_clearSampleSync(ViSession vi);	
Parameters	vi Instrument handle returned from hp4156b_init(
	hp4156b_cle	arStressSync	
	This function clear hp4156b_addStres	rs the settings of the stress sources defined by the sSyncIv function and the hp4156b_addStressSyncPulse function.	
Syntax	ViStatus _VI_FUNC hp4156b_clearStressSync(ViSession vi);		
Parameters	vi	Instrument handle returned from hp4156b_init().	
	hp4156b_close		
	This function term system resources. I handle when the pr	inates the software connection to the instrument and deallocates It is generally a good programming habit to close the instrument rogram is done using the instrument.	
Syntax	ViStatus _VI_FUNC hp4156b_close(ViSession vi);		
Parameters	vi	Instrument handle returned from hp4156b_init().	
	hp4156b_cmd		
	This function passes the cmd_str string to the instrument. Must be a NULL terminated C string.		
Syntax	ViStatus _VI_FUNC hp4156b_cmd(ViSession vi, ViString cmd_str);		
Parameters	vi	Instrument handle returned from hp4156b_init().	
	cmd_str	Instrument command (cannot exceed 256 bytes in length).	

hp4156b_cmdData_Q

This function passes the cmd_str string to the instrument. This entry point will wait for a response which may be any data. You specify the cmd_str and size parameters, and get result[].

 Syntax
 ViStatus _VI_FUNC hp4156b_cmdData_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViChar _VI_FAR result[]);

Parameters	vi	Instrument handle returned from hp4156b_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	size	Length of result in bytes. 2 to 32767.
	result[]	Response from instrument.

hp4156b_cmdInt

This function passes the cmd_str string to the instrument. This entry point passes the string in cmd_str followed by a space and then the integer in value. Note that either an Int16 or 32 can be passed as the Int16 will be promoted.

Syntax ViStatus_VI_FUNC hp4156b_cmdInt(ViSession vi, ViString cmd_str, ViInt32 value);

Parameters	vi	Instrument handle returned from hp4156b_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	value	Parameter for command2147483647 to 2147483647.

Driver Functions hp4156b_cmdInt16Arr_Q

cmd str

result

hp4156b_cmdInt16Arr_Q

	This function passes the cmd_str string to the instrument. This command expects a response that is a definite arbitrary block of 16 bit integers. You specify the cmd_st and size parameters, and get result[] and count.			
Syntax	ViStatus _VI_ ViInt32 size, V	ViStatus _VI_FUNC hp4156b_cmdInt16Arr_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViInt16 _VI_FAR result[], ViPInt32 count);		
Parameters	vi	Instrument handle returned from hp4156b_init().		
	cmd_str	Instrument command (cannot exceed 256 bytes in length).		
	size	Size of result[] (number of items in the array). 1 to 2147483647.		
	result[]	Response from instrument.		
	count	Count of valid items in result[].		
	hp4156b_cmdInt16_Q			
	This function response that	This function passes the cmd_str string to the instrument. This command expects a response that can be returned as a 16 bit integer.		
Syntax	ViStatus _VI_ ViPInt16 resu	ViStatus _VI_FUNC hp4156b_cmdInt16_Q(ViSession vi, ViString cmd_str, ViPInt16 result);		
Parameters	vi	Instrument handle returned from hp4156b_init().		

Response from instrument.

Instrument command (cannot exceed 256 bytes in length).

hp4156b_cmdInt32Arr_Q

This function passes the cmd_str string to the instrument. This command expects a response that is a definite arbitrary block of 32 bit integers. You specify the cmd_str and size parameters, and get result[] and count.

Syntax ViStatus _VI_FUNC hp4156b_cmdInt32Arr_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViInt32 _VI_FAR result[], ViPInt32 count);

Parameters	vi	Instrument handle returned from hp4156b_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	size	Size of result[] (number of items in the array). 1 to 2147483647.
	result[]	Response from instrument.
	count	Count of valid items in result].

hp4156b_cmdInt32_Q

This function passes the cmd_str string to the instrument. This command expects a response that can be returned as a 32 bit integer.

SyntaxViStatus _VI_FUNC hp4156b_cmdInt32_Q(ViSession vi, ViString cmd_str,
ViPInt32 result);ParametersviInstrument handle returned from hp4156b init().

rameters	VI	Instrument handle returned from hp4156b_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	result	Response from instrument.

Driver Functions hp4156b_cmdReal

hp4156b_cmdReal

	This function the string in cr an Real32 or 6	This function passes the cmd_str string to the instrument. This entry point passes the string in cmd_str followed by a space and then the real in value. Note that either an Real32 or 64 can be passed as the Real32 will be promoted.		
Syntax	ViStatus _VI_ ViReal64 valu	ViStatus _VI_FUNC hp4156b_cmdReal(ViSession vi, ViString cmd_str, ViReal64 value);		
Parameters	vi	Instrument handle returned from hp4156b_init().		
	cmd_str	Instrument command (cannot exceed 256 bytes in length).		
	value	Parameter for command1E+300 to 1E+300.		
	hp4156b_cmdReal64Arr_Q			
	This function passes the cmd_str string to the instrument. This command expects a response that is a definite arbitrary block of 64 bit reals. You specify the cmd_str and size parameters, and get result[] and count.			
Syntax	ViStatus _VI_ ViInt32 size, V	ViStatus _VI_FUNC hp4156b_cmdReal64Arr_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViReal64 _VI_FAR result[], ViPInt32 count);		
Parameters	vi	Instrument handle returned from hp4156b_init().		
	cmd_str	Instrument command (cannot exceed 256 bytes in length).		
	size	Size of result[] (number of items in the array). 1 to 2147483647.		
	result[]	Response from instrument.		
	count	Count of valid items in result[].		

hp4156b_cmdReal64_Q

This function passes the cmd_str string to the instrument. This command expects a response that can be returned as a 64 bit real.

Syntax ViStatus _VI_FUNC hp4156b_cmdReal64_Q(ViSession vi, ViString cmd_str, ViPReal64 result);

Parameters	vi	Instrument handle returned from hp4156b_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	result	Response from instrument.

hp4156b_cmdString_Q

This function passes the cmd_str string to the instrument. This entry point will wait for a response which must be a string (character data). You specify the cmd_str and size parameters, and get result[].

 Syntax
 ViStatus _VI_FUNC hp4156b_cmdString_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViChar _VI_FAR result[]);

Parameters	vi	Instrument handle returned from hp4156b_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	size	Length of result in bytes. 2 to 32767.
	result[]	Response from instrument.

hp4156b_dcl

This function sends a device clear (DCL) to the instrument.

A device clear will abort the present operation and enable the instrument to accept a new command or query. This is particularly useful in situations where it is not possible to determine the instrument state. In this case, it is customary to send a device clear before issuing a new instrument driver function. The device clear ensures that the instrument will be able to begin processing the new commands.

Syntax ViStatus_VI_FUNC hp4156b_dcl(ViSession vi);

Parameters vi Instrument handle returned from hp4156b_init().

Driver Functions hp4156b_error_message

hp4156b_error_message

This function translates the error return value from an instrument driver function to a readable string.

 Syntax
 ViStatus_VI_FUNC hp4156b_error_message(ViSession vi, ViStatus error_number, ViChar_VI_FAR message[]);

Parameters

vi Instrument handle returned from hp4156b_init().

error_number Error return value from the driver function.

message[] Error message string. This is limited to 256 characters.

hp4156b_error_query

This function returns the error numbers and corresponding error messages in the error queue of a instrument. See *User's Guide: Measurement and Analysis* for a listing of the instrument error numbers and messages.

Instrument errors may occur when you places the instrument in a bad state such as sending an invalid sequence of coupled commands. Instrument errors can be detected by polling. Automatic polling can be accomplished by using the hp4156b_errorQueryDetect function.

 Syntax
 ViStatus _VI_FUNC hp4156b_error_query(ViSession vi, ViPInt32 error_number, ViChar _VI_FAR error_message[]);

Parameters	vi	Instrument handle returned from hp4156b_init().
	error_number	Instrument's error code.
	error_message[]	Instrument's error message. This is limited to 256 characters.
hp4156b_errorQueryDetect

This function enables or disables automatic instrument error checking.

If automatic error checking is enabled then the driver will query the instrument for an error at the end of each function call.

Syntax ViStatus _VI_FUNC hp4156b_errorQueryDetect(ViSession vi, ViBoolean errorQueryDetect);

ParametersviInstrument handle returned from hp4156b_init().

errorQueryDetect Error checking enable (VI_TRUE) or disable (VI_FALSE).

hp4156b_errorQueryDetect_Q

This function indicates if automatic instrument error detection is enabled or disabled.

Syntax ViStatus_VI_FUNC hp4156b_errorQueryDetect_Q(ViSession vi, ViPBoolean pErrDetect);

 Parameters
 vi
 Instrument handle returned from hp4156b_init().

 pErrDetect
 Error checking enable (VI TRUE) or disable (VI FALSE).

Driver Functions hp4156b_esr_Q

hp4156b_esr_Q

This function returns the contents of the ESR register. The driver returns the equivalent messages:

Syntax	ViStatus _VI_	FUNC hp4156b_esr_Q	(ViSession vi, ViChar_VI_FAI	<pre>& errstr[]);</pre>
Parameters	vi	Instrument hand	e returned from hp4156b_init()).
	errstr[]	Response from i	nstrument.	
		Bit Value	Message	
		1	"ESR_OPC"	
		2	"ESR_RQL"	
		4	"ESR_QYE"	
		8	"ESR_DDE"	
		16	"ESR_EXE"	
		32	"ESR_CME"	
		64	"ESR_URQ"	
		128	"ESR_PON"	

hp4156b_execCal

This function executes the calibration and returns the calibration result. The parameter "result" returns the calibration result.

Syntax	ViStatus _VI	_FUNC hp4156b_execCal(ViSession vi, ViPInt32 result);
Parameters	vi	Instrument handle returned from hp4156b_init().
	result	Calibration result. Numeric number. 0: No error (calibration succeed).

hp4156b_execOffsetCancel

This function measures the zero offset data, and sets the zero offset function to ON.

The parameter 'channel' specifies the measurement channel (SMU or VMU). If you define SMU for 'channel', the SMU must be set to the voltage force mode by using the hp4156b_force function, before executing this function.

If you define VMU for 'channel', the VMU must be set to the differential voltage measurement mode by using the hp4156b_setVm function, before executing this function.

Syntax ViStatus _VI_FUNC hp4156b_execOffsetCancel(ViSession vi, ViInt32 channel, ViInt32 range);

Parameters	vi	Instrument handle returned from hp4156b_init().
	channel	Channel number of the unit to measure the zero offset data
		1 to 6 (SMU1 to SMU6), 23 (VMU1), or 24 (VMU2).
	range	Measurement range to measure the zero offset data
		0 (10 pA range for SMU), 1 (100 pA range for SMU), 2 (1 nA range for SMU), or 3 (0.2 V range for VMU).

Driver Functions hp4156b_force

hp4156b_force

	This function spec VSU, or PGU), ar hp4156b_force fu	cifies the dc current source (SMU) or dc voltage source (SMU, and forces the output immediately. To stop the output, use the nction with 0 (zero) output.	
Syntax	ViStatus _VI_FUNC hp4156b_force(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViReal64 value, ViReal64 comp, ViInt32 polarity);		
Parameters	vi	Instrument handle returned from hp4156b_init().	
	channel	Channel number of the source unit.	
		1 to 6 (SMU1 to SMU6), 21 (VSU1), 22 (VSU2), 27 (PGU1), or 28 (PGU2)	
	mode	Output mode. 1 (current output, only for SMU) or 2 (voltage output).	
	range	Output range. 0 (auto ranging) or positive value (limited auto ranging). See below.	
		For current output: 1E-11 to 1.0 A, or 0.	
		For voltage output: 2.0 to 200.0 V, or 0.	
	value	Output value1.0 to 1.0 A for current output, -200.0 to 200.0 V for SMU voltage output, -40 to 40 V for PGU dc voltage output, -20 to 20 V for VSU output.	
	comp	Compliance value (only for SMU)200.0 V to 200.0 V for voltage compliance, -1.0 to 1.0 A for current compliance.	
	polarity	Compliance polarity (only for SMU). 0 (auto) or 1 (manual). If you select 1, polarity is set to the same polarity as comp value you enterd.	

hp4156b_forcePulse

This function specifies the pulse source (PGU) settings and forces the voltage pulse immediately. To stop the pulse output, use hp4156b_abortMeasure function.

Syntax ViStatus _VI_FUNC hp4156b_forcePulse(ViSession vi, ViInt32 channel, ViInt32 count, ViReal64 base, ViReal64 peak, ViReal64 width, ViReal64 period, ViReal64 delay, ViReal64 rise, ViReal64 fall);

Parameters	vi	Instrument handle returned from hp4156b_init().
	channel	Channel number of the pulse generator unit.
		27 (PGU1) or 28 (PGU2)
	count	Pulse count (number of pulses). 1 to 65535, or 0 (free run mode).
	base	Pulse base value40.0 to 40.0 V.
	peak	Pulse peak value40.0 to 40.0 V.
	width	Pulse width. 1E-6 to 9.99 seconds.
	period	Pulse period. 1E-6 to 10.0 seconds.
	delay	Pulse delay time. 0.0 to 10.0 seconds.
	rise	Pulse leading time. 0.1E-6 to 10E-3 seconds.
	fall	Pulse trailling time. 0.1E-6 to 10E-3 seconds.

Driver Functions hp4156b_init

hp4156b_init

	This function i verifies that in actions to place	nitializes the software connection to the instrument and optionally strument is in the system. In addition, it may perform any necessary e the instrument in its reset state.
	If the hp4156b parameter will	_init function encounters an error, then the value of the vi output be VI_NULL.
Syntax	ViStatus _VI_l ViBoolean do_	FUNC hp4156b_init(ViRsrc InstrDesc, ViBoolean id_query, reset, ViPSession vi);
Parameters	InstrDesc	Instrument description. Examples; GPIB0::1::INSTR.
	id_query	VI_TRUE (to perform system verification), or VI_FALSE (do not perform system verification).
	do_reset	VI_TRUE (to perform reset operation), or VI_FALSE (do not perform reset operation).
	vi	Instrument handle. This is VI_NULL if an error occurred during the init.

hp4156b_measureM

	This function exec	utes a multi channel spot mea	asurement by the specified units, and
	The array size of a data is important. channel[1] must be status data of the u status[1], respectiv	Il arrays should be the same to For example, the measureme e entered into mode[1] and ra mits specified by channel[1] vely.	together. Then the order of the array ent setup for the unit specified by unge[1]. And the measured data and will be returned by value[1] and
Syntax	ViStatus _VI_FUN ViInt32 mode[], V	VC hp4156b_measureM(ViSe /iReal64 range[], ViReal64 v	ession vi, ViInt32 channel[], /alue[], ViInt32 status[]);
Parameters	vi	Instrument handle returned	from hp4156b_init().
	channel[]	Channel number of the mea end of the unit definition for two units, the first and seco specify the units, and the th	asurement unit. Enter 0 (zero) at the or channel[]. For example, if you use ond elements of channel[] must hird element must be 0.
		1 to 6 (SMU1 to SMU6), 2	3 (VMU1), or 24 (VMU2).
	mode[]	Measurement mode.	
		1 (current measurement) or	2 (voltage measurement).
	range[]	Measurement range. 0 (aut auto ranging), or negative	o ranging), positive value (limited value (fixed range). See below.
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.
	value[]	Measurement data.	
	status[]	Measurement status. 0 (no	error), or 1 to 255 (error status).

Driver Functions hp4156b_measureP

Parameters

hp4156b_measureP

This function executes a pulsed spot measurement by the specified channel, and returns the measured value and the measurement status.

Syntax ViStatus _VI_FUNC hp4156b_measureP(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViPReal64 value, ViPInt32 status);

	vi	Instrument handle returned from hp4156b_init().			
	channel	Channel number of the measurement unit.			
		1 to 6 (SMU1 to SMU6), 23 (VMU1), or 24 (VMU2).			
	mode	Measurement mode. 1 (curr 2 (voltage measurement).	rent measurement, only for SMU) or		
	range	Measurement range. 0 (auto ranging), positive value auto ranging), or negative value (fixed range). See be			
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.		
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.		
	value	Measurement data.			
	status	Measurement status. 0 (no error), or 1 to 255 (error status).			

hp4156b_offsetCancel

This function enables or disables the zero offset cancel function.

SyntaxViStatus _VI_FUNC hp4156b_offsetCancel(ViSession vi, ViInt32 channel,
ViInt32 state);ParametersviInstrument handle returned from hp4156b_init().

VI	Instrument handle returned from hp4156b_init().
channel	Channel number of the unit to set the offset cancel function.
	1 to 6 (SMU1 to SMU6), 23 (VMU1), or 24 (VMU2).
state	0 (Function OFF), or 1 (Function ON).

hp4156b_opc_Q

status

channel

This function does the *OPC? common command.

Syntax	ViStatus _VI_I	FUNC hp4156b_opc_Q(ViSession vi, ViPBoolean result);
Parameters	vi	Instrument handle returned from hp4156b_init().
	result	VI_TRUE (Operation complete), or VI_FALSE (Operation is pending).
	hp4156b_	readData
	This function r hp4156b_start	eads and returns the source setup data or the data measured by the Measure function.
Syntax	ViStatus _VI_I ViPInt32 data_	FUNC hp4156b_readData(ViSession vi, ViPInt32 eod, type, ViPReal64 value, ViPInt32 status, ViPInt32 channel);
Parameters	vi	Instrument handle returned from hp4156b_init().
	eod	End of data flag. 0 (not end of data), or 1 (end of data).
	data_type	 Data type of the value. 0 (Voltage setup data), 1 (Current setup data), 3 (Time setup data), 8 (Voltage measurement data), 9 (Current measurement data), 11 (Time measurement data), 14 (Sampling index data), or 15 (Stress status data).
	value	Measurement data or source setup data.

Measurement status or source status.

24 (VMU2), 27 (PGU1) or 28 (PGU2).

Channel number of the unit for measurement or output.

1 to 6 (SMU1 to SMU6), 21 (VSU1), 22 (VSU2), 23 (VMU1),

	Driver Function hp4156b_read	ons dStatusByte_Q		
	hp4156b_	readStatusByte_Q		
	This function r	eturns the contents of the status byte register.		
Syntax	ViStatus _VI_FUNC hp4156b_readStatusByte_Q(ViSession vi, ViPInt16 statusByte);			
Parameters	vi	Instrument handle returned from hp4156b_init().		
	statusByte	The contents of the status byte are returned in this parameter.		
	hp4156b_recoverOutput			
	This function returns the unit to the settings that are stored by the hp4156b_zeroOutput function, and clears the stored unit settings.			
Syntax	ViStatus _VI_FUNC hp4156b_recoverOutput(ViSession vi, ViInt32 channel);			
Parameters	vi	Instrument handle returned from hp4156b_init().		
	channel	Channel number of the unit to return the settings. 1 to 6 (SMU1 to SMU6), 21 (VSU1), 22 (VSU2), 27 (PGU1) or 28 (PGU2).		
	hp4156b_reset			
	This function p may be necessa reset. A device	places the instrument in a default state. Before issuing this function, it ary to send a device clear to ensure that the instrument can execute a e clear can be issued by invoking hp4156b_dcl function.		
Syntax	ViStatus _VI_F	FUNC hp4156b_reset(ViSession vi);		
Parameters	vi	Instrument handle returned from hp4156b_init().		

hp4156b_revision_query

This function returns the driver revision and the instrument firmware revision.

Syntax	ViStatus _VI_FUNC hp4156b_revision_query(ViSession vi, ViChar_VI_FAR driver_rev[], ViChar_VI_FAR instr_rev[]);		
Parameters	vi	Instrument handle returned from hp4156b_init().	

driver_rev[] Instrument driver revision. This is limited to 256 characters.

instr_rev[] Instrument firmware revision. This is limited to 256 characters.

Driver Functions hp4156b_sample

hp4156b_sample

	This function ex returns the num data and the me	xecutes a sampling measuremen ber of measurement points, mea easurement status.	t by the specified channels, and asurement data index, measurement	
	Before executir hp4156b_setSa measurement u And the synchr defined by usin	ng this function, set the sampling mple function. The synchronou nits are defined by using the hp ⁴ onous pulsed sources used with g the hp4156b_addSampleSync	g timing by using the s dc sources used with the sampling 4156b_addSampleSyncIv function. the sampling measurement units are Pulse function.	
Syntax	ViStatus _VI_F ViInt32 mode[ViReal64 value	UNC hp4156b_sample(ViSessio], ViReal64 range[], ViPInt32 p [], ViInt32 status[]);	on vi, ViInt32 channel[], point, ViInt32 index[],	
Parameters	vi	Instrument handle returned from hp4156b_init().		
	channel[]	Channel number of the me	asurement unit.	
		1 to 6 (SMU1 to SMU6), 2	3 (VMU1), or 24 (VMU2).	
	mode[]	Measurement mode. 1 (current measurement, only for SMU) or 2 (voltage measurement).		
	range[]	Measurement range. 0 (auto ranging), positive value (limited auto ranging), or negative value (fixed range). See below.		
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.	
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.	
	point	Number of measurement p	Number of measurement points. 1 to 10001.	
	index[]	Measurement data index.		
	value[]	Measurement data.		
	status[]	Measurement status. 0 (no	error), or 1 to 255 (error status).	

Remarks The array size of the parameters should be as shown below. ViInt32 channel[N] ViInt32 mode[N] ViReal64 range[N] ViInt32 point ViInt32 index[M] ViReal64 value[M][N] ViReal64 status[M][N] where. N: Number of channels used for the measurements plus 1, or more. M: Number of sweep points ('point' parameter value of hp4156b setSample function), or more. For the parameter definition, the order of the array data is important. For example, the measurement setup for the unit specified by channel[1] must be entered into mode[1] and range[1]. And measurement data and status data of the unit specified by channel[1] will be returned by value[M][1] and status[M][1], respectively. hp4156b self test This function causes the instrument to perform a self-test and returns the result of that self-test. This is used to verify that an instrument is operating properly. A failure may indicate a potential hardware problem. Syntax ViStatus VI FUNC hp4156b self test(ViSession vi, ViPInt16 test result,

Parameters	vi	Instrument handle returned from hp4156b_init().
	test_result	Numeric result from self-test operation. 0: No error.
	test_message[]	Self-test status message. This is limited to 256 characters.

ViChar VI FAR test message[]);

Driver Functions hp4156b_setFilter

Parameters

hp4156b_setFilter

This function sets the output filter of the specified channel.

Syntax ViStatus_VI_FUNC hp4156b_setFilter(ViSession vi, ViInt32 channel, ViInt32 state);

vi	Instrument handle returned from hp4156b_init().
channel	Channel number of the unit. 1 (SMU1), 2, 3, 4, 5, or 6 (SMU6).
state	0 (Filter OFF) or 1 (Filter ON).

hp4156b_setInteg

This function sets the integration time, and sets the number of samples that are taken and averaged for the measurement.

Syntax ViStatus_VI_FUNC hp4156b_setInteg(ViSession vi, ViInt32 table, ViReal64 time, ViInt32 average);

Parameters	vi	Instrument handle returned from hp4156b_init().
	table	Integration time table. 1 (short), 2 (medium), or 3 (long).
	time	Integration time. in seconds. 80E-6 to 10.16E-3 for table=1, or 16.7E-3 to 2.0 for table=3. Ignore this parameter for table=2.
	average	Number of samples for averaging. 1 to 1023, or 0. If you do not want to change the value from previous value, enter 0.

hp4156b_setIv

	This function sp ments and the s ters. For the stat synchronizes w	becifies the sweep source channel for the staircase sweep measure- taircase sweep with pulsed bias measurements, and sets the parame- ircase sweep with pulsed bias measurements, the sweep output ith the pulse output by the hp4156b_setPbias function.
Syntax	ViStatus _VI_F ViReal64 range ViReal64 delay	UNC hp4156b_setIv(ViSession vi, ViInt32 channel, ViInt32 mode, , ViReal64 start, ViReal64 stop, ViInt32 point, ViReal64 hold, , ViReal64 s_delay, ViReal64 comp, ViReal64 p_comp);
Parameters	vi	Instrument handle returned from hp4156b_init().
	channel	Channel number of the sweep source.
		1 to 6 (SMU1 to SMU6), 21 (VSU1), or 22 (VSU2).
	mode	Output mode. 1 (single linear), 2 (single log), 3 (double linear), or 4 (double log). Use positive value for voltage output, use negative value for current output (only for SMU).
	range	Output range. 0 (auto ranging) or positive value (limited auto ranging). See below.
		For current output: 1E-11 to 1.0 A, or 0.
		For voltage output: 2.0 to 200.0 V, or 0.
	start	Sweep start value1.0 to 1.0 A, or -200.0 to 200.0 V.
	stop	Sweep stop value1.0 to 1.0 A, or -200.0 to 200.0 V.
	point	Number of sweep steps. 1 to 1001.
	hold	Hold time. 0 to 655.35 seconds.
	delay	Delay time. 0 to 65.535 seconds.
	s_delay	Step delay time. 0 to 1.0 second.
	comp	Compliance value200.0 V to 200.0 V for voltage compliance, -1.0 to 1.0 A for current compliance.
	p_comp	Power compliance. 1.0 to 20.0.

Driver Functions hp4156b_setPbias

hp4156b_setPbias

	This function and the stairca	specifies the pulse output channel for the pulsed spot measurements use sweep with pulsed bias measurements, and sets the parameters.		
	For the stairca synchronizes	For the staircase sweep with pulsed bias measurements, the pulse output synchronizes with the staircase sweep output by the hp4156b_setIv function.		
Syntax	ViStatus _VI_ ViInt32 mode ViReal64 peri	ViStatus _VI_FUNC hp4156b_setPbias(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViReal64 base, ViReal64 peak, ViReal64 width, ViReal64 period, ViReal64 hold, ViReal64 comp);		
Parameters	vi	Instrument handle returned from hp4156b_init().		
	channel	Channel number of the pulse source.		
		1 to 6 (SMU1 to SMU6), 21 (VSU1), or 22 (VSU2).		
	mode	Pulse output mode. 1 (current output, only for SMU), or 2 (voltage output).		
	range	Output range. 0 (auto ranging) or positive value (limited auto ranging). See below.		
		For current output: 1E-11 to 1.0 A, or 0.		
		For voltage output: 2.0 to 200.0 V, or 0.		
	base	Pulse base value1.0 to 1.0 A, or -200.0 to 200.0 V.		
	peak	Pulse peak value1.0 to 1.0A, or -200.0 to 200.0 V.		
	width	Pulse width. 0.5E-3 to 100E-3 seconds.		
	period	Pulse period. 5E-3 to 1.0 seconds.		
	hold	Hold time. 0.0 to 655.35 seconds.		
	comp	Compliance value200.0 V to 200.0 V for voltage compliance, -1.0 to 1.0 A for current compliance.		

hp4156b_setPguR

This function sets the PGU output impedance.

Syntax	ViStatus _VI_ ViInt32 state)	FUNC hp4156b_setPguR(ViSession vi, ViInt32 channel,
Parameters	vi	Instrument handle returned from hp4156b_init().
	channel	Channel number of PGU.
		27 (PGU1) or 28 (PGU2).
	state	PGU output impedance.
		0 (approx. 0 ohm low impedance) or 1 (50 ohm).

Driver Functions hp4156b_setPiv

Parameters

hp4156b_setPiv

This function specifies the pulsed sweep source channel for the pulsed sweep measurements, and sets the parameters.

Syntax ViStatus_VI_FUNC hp4156b_setPiv(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViReal64 base, ViReal64 start, ViReal64 stop, ViInt32 point, ViReal64 hold, ViReal64 width, ViReal64 period, ViReal64 comp);

vi	Instrument handle returned from hp4156b_init().		
channel	Channel number of the pulse sweep source.		
	1 to 6 (SMU1 to SMU6), 21 (VSU1), or 22 (VSU2).		
mode	Output mode. 1 (single linear), 2 (single log), 3 (double linear), or 4 (double log). Use positive value for voltage output, use negative value for current output (only for SMU).		
range	Output range. 0 (auto ranging) or positive value (limited auto ranging). See below.		
	For current output: 1E-11 to 1.0 A, or 0.		
	For voltage output: 2.0 to 200.0 V, or 0.		
base	Pulse sweep base value1.0 to 1.0 A, or -200.0 to 200.0 V.		
start	Pulse sweep start value1.0 to 1.0A, or -200.0 to 200.0 V.		
stop	Pulse sweep stop value1.0 to 1.0A, or -200.0 to 200.0 V.		
point	Number of sweep steps. 1 to 1001.		
hold	Hold time. 0.0 to 655.35 seconds.		
width	Pulse width. 0.5E-3 to 100E-3 seconds.		
period	Pulse period. 5E-3 to 1.0 seconds.		
comp	Compliance value200.0 V to 200.0 V for voltage compliance, -1.0 to 1.0 A for current compliance.		

hp4156b_setSample

This function specifies the measurement timing of the sampling measurements. The sampling measurement units are defined by the hp4156b_sample function.

Syntax ViStatus _VI_FUNC hp4156b_setSample(ViSession vi, ViReal64 hold, ViReal64 interval, ViInt32 point);

Parameters	vi	Instrument handle returned from hp4156b_init().
	hold	Hold time30E-3 to 655.35 seconds.
	interval	Sampling interval. 60E-6 to 65.534 seconds.
	point	Number of sampling points. 1 to 10001.

hp4156b_setStress

This function sets the timing parameters of the stress. See "hp4156b_stress" on page 41 for the setting of period parameter.

SyntaxViStatus _VI_FUNC hp4156b_setStress(ViSession vi, ViReal64 hold,
ViInt32 mode, ViReal64 duration, ViReal64 period);

Parameters	vi	Instrument handle returned from hp4156b_init().
	hold	Hold time. 0 to 655.35 seconds.
	mode	Stress mode. 1 (pulse count mode) or 2 (duration mode).
	duration	Number of pulse count (1 to 65535) for mode=1, or Duration time (500E-6 to 655.0 seconds) for mode=2.
	period	Pulse period. 2E-6 to 10.0 seconds.

Driver Functions hp4156b_setSweepSync

hp4156b_setSweepSync

	This function speci sweep measuremen pulsed bias measure used for the staircas	fies the synchronous sweep source channel for the staircase ts, the pulsed sweep measurements and the staricase sweep with ements, and sets the parameters. Synchronous sweep source is se sweep.	
	For the staircase sweep measurements, the output synchronizes with the staircase sweep output by the hp4156b_setIv function.		
	For the pulsed sweep measurements, the output synchronizes with the pulsed sweep output by the hp4156b_setPiv function.		
	For the staircase sweep with pulsed bias measurements, the output synchronizes the staircase sweep output by the hp4156b_setIv function and the pulse output by the hp4156b_setPbias function.		
Syntax	ViStatus _VI_FUN ViInt32 mode, ViRe ViReal64 p_comp);	C hp4156b_setSweepSync(ViSession vi, ViInt32 channel, eal64 range, ViReal64 start, ViReal64 stop, ViReal64 comp,	
Parameters	vi	Instrument handle returned from hp4156b_init().	
	channel	Channel number of the sweep source.	
		1 to 6 (SMU1 to SMU6), 21 (VSU1), or 22 (VSU2).	
	mode	Output mode. 1 (current output, only for SMU) or 2 (voltage output).	
	range	Output range. 0 (auto ranging) or positive value (limited auto ranging). See below.	
		For current output: 1E-11 to 1.0 A, or 0.	
		For voltage output: 2.0 to 200.0 V, or 0.	
	start	Sweep start value1.0 to 1.0 A, or -200.0 to 200.0 V.	
	stop	Sweep stop value1.0 to 1.0 A, or -200.0 to 200.0 V.	
	comp	Compliance value200.0 V to 200.0 V for voltage compliance, -1.0 to 1.0 A for current compliance.	
	p_comp	Power compliance. 1.0 to 20.0.	

hp4156b_setSwitch

This function sets the output switch of the specified channel.

Syntax	ViStatus _VI_ ViInt32 state)	FUNC hp4156b_setSwitch(ViSession vi, ViInt32 channel,
Parameters	vi	Instrument handle returned from hp4156b_init().
	channel	Channel number of the unit.
		1 to 6 (SMU1 to SMU6), 21 (VSU1), 22 (VSU2), 23 (VMU1), 24 (VMU2), 26 (GNDU), 27 (PGU1) or 28 (PGU2).
	state	Output switch setting.
		0 (output switch OFF) or 1 (output switch ON).

hp4156b_setVm

This function sets the VMU measurement mode.

Syntax	ViStatus _VI	_FUNC hp4156b_setVm(ViSession vi, ViInt32 mode);
Parameters	vi	Instrument handle returned from hp4156b_init().
	mode	VMU measurement mode.
		1 (grounded mode) or 2 (differential mode).

Driver Functions hp4156b_spotMeas

Parameters

hp4156b_spotMeas

This function executes a high speed spot measurement by the specified channel, and returns the measured value and the measurement status.

Syntax ViStatus _VI_FUNC hp4156b_spotMeas(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViPReal64 value, ViPInt32 status);

	vi	Instrument handle returned from hp4156b_init().			
	channel	Channel number of the measurement unit.			
		1 to 6 (SMU1 to SMU6), 23	3 (VMU1), or 24 (VMU2).		
	mode	Measurement mode.			
		1 (current measurement, only for SMU) or 2 (voltage measurement).			
range Meas		Measurement range.	Measurement range.		
		0 (auto ranging), positive value (limited auto rang negative value (fixed range). See below.			
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.		
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.		
	value	Measurement data.			
	status	Measurement status. 0 (no error), or 1 to 255 (error status).			

hp4156b_startMeasure

	This function starts the specified measurement by the specified channels. You read the measured data by using the hp4156b_readData function. The measure data is entered to the 4155B/4156B output buffer in the measurement order. If want to abort the measurement, use the hp4156b_abortMeasure function.		by the specified channels. You can adData function. The measurement er in the measurement order. If you b_abortMeasure function.
	The array size of all arrays should be the same together. Then the order of the array data is important. For example, the measurement setup for the unit specified by channel[1] must be entered into mode[1] and range[1].		
Syntax	ViStatus _VI_FUNC hp4156b_startMeasure(ViSession vi, ViInt32 meas_type, ViInt32 channel[], ViInt32 mode[], ViReal64 range[], ViInt32 source);		Session vi, ViInt32 meas_type, ange[], ViInt32 source);
Parameters	vi	Instrument handle returned	from hp4156b_init().
	meas_type	Measurement type. 1 (multi 3 (pulse spot), 4 (pulse swe 10 (sampling), or 11 (stress	i spot), 2 (staircase sweep), ep), 5 (sweep with pulsed bias), force).
	channel[] Channel number of the measurement unit. Enter 0 (zero end of the unit definition for channel[]. For example, if two units, the first and second elements of channel[] m specify the units, and the third element must be 0.		surement unit. Enter 0 (zero) at the r channel[]. For example, if you use nd elements of channel[] must ird element must be 0.
		1 to 6 (SMU1 to SMU6), 23	3 (VMU1), or 24 (VMU2).
mode[] Measurement mode. 1 (current measurement, only 2 (voltage measurement).		rent measurement, only for SMU) or	
	range[]	Measurement range. 0 (auto auto ranging), or negative v	o ranging), positive value (limited value (fixed range). See below.
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.
	source	Source data output mode.	
		0 (measurement data output 1 (measurement data output	t without source data) or twith source data).

Driver Functions hp4156b_stopMode

hp4156b_stopMode

	This function specific function for the sweet this function specific sweep measurement	fies the stop condition which enables the automatic abort eep measurement, sampling measurement, or stress force. Also ies the sweep source output of the measurement unit after the t is aborted.
Syntax	ViStatus _VI_FUN ViInt32 tcc_stop, V	C hp4156b_stopMode(ViSession vi, ViInt32 occ_stop, iInt32 ovf_stop, ViInt32 osc_stop, ViInt32 last_mode);
Parameters	vi	Instrument handle returned from hp4156b_init().
	occ_stop	Automatic abort function by compliance of another unit.
		0 (disables this abort mode) or 1 (enables this abort mode).
	tcc_stop	Automatic abort function by compliance of this unit.
		0 (disables this abort mode) or 1 (enables this abort mode).
	ovf_stop	Automatic abort function by overflow of AD converter.
		0 (disables this abort mode) or 1 (enables this abort mode).
	osc_stop	Automatic abort function by oscillation of unit(s).
		0 (disables this abort mode) or 1 (enables this abort mode).
	last_mode	Source output value after abort condition.
		1 (returns to start value), or 2 (keeps the value when aborted).

hp4156b_stress

This function forces the stress defined by the hp4156b_setStress, hp4156b_addStressSyncIv, and hp4156b_addStressSyncPulse functions.

Syntax	ViStatus _VI_FUNC hp4156b_stress(ViSession vi, ViPInt32 status);	
Parameters	vi	Instrument handle returned from hp4156b_init().
	status	Stress output status. 0 (no error), or 1 to 255 (error status).

Remarks The following parameters must be set within the range shown in the following table. The period is a parameter of hp4156b_setStress function. And width and delay are parameters of hp4156b_addStressSyncPulse function.

period	width	delay
2E-6 to 100E-6 sec	1E-6 to 99.9E-6 sec	0 to 100E-6 sec
100E-6 to 1E-3 sec	1E-6 to 999E-6 sec	0 to 1E-3 sec
1E-3 to 10E-3 sec	10E-6 to 9.99E-3 sec	0 to 10E-3 sec
10E-3 to 100E-3 sec	100E-6 to 99.9E-3 sec	0 to 100E-3 sec
100E-3 to 1.0 sec	1E-3 to 999E-3 sec	0 to 1.0 sec
1.0 to 10.0 sec	10E-3 to 9.99 sec	0 to 10.0 sec

Driver Functions hp4156b_sweeplv

hp4156b_sweepIv

	This function executes a staircase sweep measurement by the specified channel, and returns the number of measurement points, sweep source data, measurement data and the measurement status.			
	Before executing this function, set the sweep source setup by using the hp4156b_setIv function. If you want to use the synchronous sweep source, ex the hp4156b_setSweepSync function.			
	The array size of so greater than or equa function ('point' par	urce, value and status should Il to the number of sweep po rameter).	be the same together, and it must be ints defined by the hp4156b_setIv	
Syntax	ViStatus _VI_FUNC hp4156b_sweepIv(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViPInt32 point, ViReal64 source[], ViReal64 value[], ViInt32 status[]);			
Parameters	vi Instrument handle returned from hp4156b init().		from hp4156b_init().	
	channel	Channel number of the measurement unit.		
		1 to 6 (SMU1 to SMU6), 23 (VMU1), or 24 (VMU2).		
	mode	Measurement mode. 1 (current measurement, only for SMU) or 2 (voltage measurement).		
	range	Measurement range. 0 (auto auto ranging), or negative v	ranging), positive value (limited alue (fixed range). See below.	
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.	
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.	
	point	Number of measurement points. 1 to 1001.		
	source[]	Sweep source setup data.		
	value[]	Measurement data.		
	status[]	Measurement status. 0 (no error), or 1 to 255 (error status).		

hp4156b_sweepMiv

	This function executes a multichannel staircase sweep measurement by the specified channels, and returns the number of measurement points, sweep source data, measurement data and the measurement status.			
	Before executir hp4156b_setIv the hp4156b_se	ng this function, set the sweep so function. If you want to use the etSweepSync function.	burce setup by using the synchronous sweep source, execute	
Syntax	ViStatus _VI_F ViInt32 mode[ViReal64 value	ViStatus _VI_FUNC hp4156b_sweepMiv(ViSession vi, ViInt32 channel[], ViInt32 mode[], ViReal64 range[], ViPInt32 point, ViReal64 source[], ViReal64 value[], ViInt32 status[]);		
Parameters	vi	Instrument handle returned	Instrument handle returned from hp4156b_init().	
	channel[]	Channel number of the me end of the unit definition fo two units, the first and seco specify the units, and the th	Channel number of the measurement unit. Enter 0 (zero) at the end of the unit definition for channel[]. For example, if you use two units, the first and second elements of channel[] must specify the units, and the third element must be 0.	
		1 to 6 (SMU1 to SMU6), 2	3 (VMU1), or 24 (VMU2).	
	mode[]	Measurement mode. 1 (current measurement, only for SMU) or 2 (voltage measurement).		
	range[]	Measurement range. 0 (aut auto ranging), or negative	Measurement range. 0 (auto ranging), positive value (limited auto ranging), or negative value (fixed range). See below.	
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.	
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.	
	point	Number of measurement p	oints. 1 to 1001.	
	source[]	Sweep source setup data.	Sweep source setup data.	
	value[]	Measurement data. Two di	mentional array.	
	status[]	Measurement status. 0 (no Two dimensional array.	Measurement status. 0 (no error), or 1 to 255 (error status). Two dimensional array.	

Driver Functions hp4156b_sweepMiv

RemarksThe array size of the parameters should be as shown below.ViInt32channel[N]ViInt32 mode[N]ViReal64 range[N]ViReal64 range[N]ViInt32 pointViReal64 source[M]ViReal64 source[M]ViReal64 status[M][N]ViReal64 status[M][N]where,N:N:Number of channels used for the measurements plus 1, or more.M:Number of sweep points ('point' parameter value of hp4156b_setIv function), or more.

For the parameter definition, the order of the array data is important. For example, the measurement setup for the unit specified by channel[1] must be entered into mode[1] and range[1]. And measurement data and status data of the unit specified by channel[1] will be returned by value[M][1] and status[M][1], respectively.

hp4156b_sweepPbias

	This function executes a staircase sweep with pulsed bias measurement by the specified channel, and returns the number of measurement points, sweep source data, measurement data, and the measurement status. Before executing this function, set the sweep source setup and pulsed bias setup by using the hp4156b_setIv function and the hp4156b_setPbias function. If you want to use the synchronous sweep source, execute the hp4156b_setSweepSync function. The array size of source, value and status should be the same together, and it must be greater than or equal to the number of sweep points defined by the hp4156b_setIv function ('point' parameter).		
Syntax	ViStatus _VI_FUNC hp4156b_sweepPbias(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViPInt32 point, ViReal64 source[], ViReal64 value[], ViInt32 status[]);		ession vi, ViInt32 channel, ViReal64 source[],
Parameters	vi	Instrument handle returned	from hp4156b_init().
	channel	Channel number of the mea	surement unit.
		1 to 6 (SMU1 to SMU6), 23	3 (VMU1), or 24 (VMU2).
modeMeasurement mode. 1 (current measurement, or 2 (voltage measurement).		ent measurement, only for SMU) or	
	range	Measurement range. 0 (auto auto ranging), or negative v	alue (fixed range). See below.
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.
	point	Number of measurement points. 1 to 1001.	
	source[]	Sweep source setup data.	
	value[]	Measurement data.	
	status[]	Measurement status. 0 (no e	error), or 1 to 255 (error status).

Driver Functions hp4156b_sweepPiv

hp4156b_sweepPiv

	This function executes a pulsed sweep measurement by the specified channel, and returns the number of measurement points, sweep source data, measurement value and the measurement status.		
	 Array size of source, value and status should be the same together, and it must be greater than or equal to the number of sweep points defined by the hp4156b_setF function ('point' parameter). Before executing this function, set the pulsed sweep source setup by using the hp4156b_setPiv function. If you want to use the synchronous sweep source, execute the hp4156b_setSweepSync function. 		
Syntax	ViStatus_VI_FUN ViInt32 mode, ViF ViReal64 value[],	ViStatus_VI_FUNC hp4156b_sweepPiv(ViSession vi, ViInt32 channel, ViInt32 mode, ViReal64 range, ViPInt32 point, ViReal64 source[], ViReal64 value[], ViInt32 status[]);	
Parameters	vi Instrument handle returned from hp4156b_init().		from hp4156b_init().
	channel	Channel number of the measurement unit.	
		1 to 6 (SMU1 to SMU6), 23 (VMU1), or 24 (VMU2).	
	mode	Measurement mode. 1 (cur 2 (voltage measurement).	rent measurement, only for SMU) or
	range	Measurement range. 0 (aut auto ranging), or negative	o ranging), positive value (limited value (fixed range). See below.
		For current measurement:	-1E-11 to -1.0 A, 1E-11 to 1.0 A, or 0.
		For voltage measurement:	-2.0 to -200.0 V, 2.0 to 200.0 V (-0.2 and 0.2 are available for VMU in differential mode), or 0.
	point	Number of measurement points. 1 to 1001.	
	source[]	Sweep source setup data.	
	value[]	Measurement data.	
	status[]	Measurement status. 0 (no error), or 1 to 255 (error status).	

hp4156b_timeOut

	This function sets a minimum timeout value for driver I/O transactions in milliseconds. The default timeout period is 5 seconds.	
Syntax	ViStatus_VI_F	UNC hp4156b_timeOut(ViSession vi, ViInt32 timeOut);
Parameters	vi	Instrument handle returned from hp4156b_init().
	timeOut	I/O timeout value for all functions in the driver. in milliseconds. 0 to 2147483647.
	hp4156b_	timeOut_Q
	This function r	eturns the timeout value for driver I/O transactions in milliseconds.
Syntax	ViStatus_VI_F	UNC hp4156b_timeOut_Q(ViSession vi, ViPInt32 pTimeOut);
Parameters	vi	Instrument handle returned from hp4156b_init().
	pTimeOut	Minimum timeout period that the driver can be set to, in milliseconds.
hp4156b_zeroOutput		zeroOutput
	This function s output. To reco	tores the measurement setup of the units, and sets the units to 0 V over the setup, execute hp4156b_recoverOutput function.
Syntax	ViStatus_VI_F	UNC hp4156b_zetoOutput(ViSession vi, ViInt32 channel);
Parameters	vi	Instrument handle returned from hp4156b_init().
	channel	Channel number of the unit to set to the zero output.
		0 (all unit), 1 to 6 (SMU1 to SMU6), 21 (VSU1), 22 (VSU2), 27 (PGU1), or 28 (PGU2).

Driver Functions for the E5250A

Table 2-2 lists all the functions for the E5250A. You will see a brief description of the functions in the table.

For the description, syntax and parameters of the function, refer to the reference section following this table. The driver functions in the reference section will appear in the alphabetical order.

Category	Function	Description
Miscellaneous	hpe5250a_init	Initializes the E5250A.
	hpe5250a_close	Closes the connection with the E5250A.
	hpe5250a_reset	Executes the E5250A reset.
	hpe5250a_self_test	Executes the E5250A self-test.
	hpe5250a_error_query	Queries for the E5250A error code/message.
	hpe5250a_error_message	Queries for the driver error.
	hpe5250a_revision_query	Queries for the E5250A firmware/driver revisions.
	hpe5250a_timeOut	Sets the timeout.
	hpe5250a_timeOut_Q	Queries for the timeout setting.
	hpe5250a_errorQueryDetect	Sets the automatic error checking.
	hpe5250a_errorQueryDetect_Q	Queries for the automatic error checking setting.
	hpe5250a_dcl	Sends the Device Clear.
	hpe5250a_esr_Q	Queries for the ESR status.
	hpe5250a_readStatusByte_Q	Reads the E5250A status byte.
	hpe5250a_opc_Q	Checks the E5250A operation completion status.
Mode Control	hpe5250a_func	Sets the configuration mode.
	hpe5250a_connRuleSeq	Sets the connection rule/sequence.
Bias Mode	hpe5250a_biasPort	Selects the input bias port.
	hpe5250_biasChanCard	Selects the card for bias mode.
	hpe5250_biasChanList	Selects the channel list for bias mode.
	hpe5250a_biasState	Sets the bias port state.
	hpe5250a biasChanList Q	Queries for the bias channel list.

Table 2-2E5250A Driver Function Lists

Category	Function	Description	
Couple Port	hpe5250a_couplePort	Selects the couple port.	
	hpe5250a_coupleState	Sets the couple port state.	
Route Control	hpe5250a_closeList	Closes the channel list.	
	hpe5250a_openList	Opens the channel list.	
	hpe5250a_openCard	Opens all output on the card.	
	hpe5250a_closeList_Q	Queries for the channel list status.	
	hpe5250a_openList_Q		
	hpe5250a_closeCard_Q	Queries for the closed channel list on the card.	
C/G	hpe5250a_CompenC	Executes the C/G compensation.	
Compensation	hpe5250a_selectCompenFile	Selects the compensation data file.	
Diagnostics	hpe5250a_testExec_Q	Executes the relay/front-panel/controller test.	
	hpe5250a_testClear	Clears the test result.	
Passthrough	hpe5250a_cmd	Sends a command.	
Functions	hpe5250a_cmdInt	Sends a command with an integer parameter.	
	hpe5250a_cmdReal	Sends a command with a real parameter.	
	hpe5250a_cmdData_Q	Sends a command to read any data.	
	hpe5250a_cmdString_Q	Sends a command to read string response.	
	hpe5250a_cmdInt16_Q	Sends a command to read 16 bit integer response.	
	hpe5250a_cmdInt16Arr_Q	Sends a command to read 16 bit integer array response.	
	hpe5250a_cmdInt32_Q	Sends a command to read 32 bit integer response.	
	hpe5250a_cmdInt32Arr_Q	Sends a command to read 32 bit integer array response.	
	hpe5250a_cmdReal64_Q	Sends a command to read 64 bit real response.	
	hpe5250a_cmdReal64Arr_Q	Sends a command to read 64 bit real array response.	

Driver Functions hpe5250a_biasChanCard

hpe5250a biasChanCard

This function will enable or disable bias on all the output ports of the specified card.

Syntax ViStatus VI FUNC hpe5250a biasChanCard(ViSession vi, ViInt16 disable enable, ViInt16 bias cardno);

Parameters

Parameters

vi	Instrument handle returned from hpe5250a_init().
disable_enable	Bias status.
	0 : sets bias enabled card.
	1 : sets bias disabled card.
bias_cardno	Card number. 1 (card 1), 2 (card 2), 3 (card 3), 4 (card 4), or 5 (all card) in the normal configuration mode, or 0 (all card in the automatic configuration mode). For the configuration mode, see hpe5250a_func.

hpe5250a biasChanList

This function will enable or disable bias on all the output ports specified by the biaschan list.

The parameter 'biaschan list' is an array of integers with each integer representing one channel. The last number of the 'biaschan list' should be "0" (numeric zero) to identify the end of the list. The maximum number of channels that can be specified by the list is 100.

Syntax ViStatus VI FUNC hpe5250a biasChanList(ViSession vi, ViInt16 biaschan disen, ViInt32 VI FAR biaschan list[]);

vi	Instrument handle returned from hpe5250a_init().
biaschan_disen	Bias status.
	0 : sets bias enabled port.
	1 : sets bias disabled port.
biaschan_list[]	Channel numbers. 5 digits integer. ABCDE. where A: card number, BC: input port number, DE: output port number. Top zero(s) can be ignored. For example, if A=0, BC=01, and DE=01, channel number should be 101 instead of 00101.

hpe5250a_biasChanList_Q

	This function will the list.	query the instrument for the bias status for the channels given in		
	The parameter 'biaschan_list' is an array of integers with each integer representing one channel. The last number of the 'biaschan_list' should be "0" (numeric zero) to identify the end of the list. The maximum number of channels that can be specified by the list is 100.			
	The 'bias_status' parameter is an array of integers containing the return values of the query. The 'bias_status' array returned will correspond one to one with 'biaschan_list' parameter.			
Syntax	ViStatus _VI_FUNC hpe5250a_biasChanList_Q(ViSession vi, ViInt16 bias_disen, ViInt32 _VI_FAR biaschan_list[], ViInt32 _VI_FAR bias_status[]);			
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	bias_disen	Bias status for the query.		
		0 : confirms if the port is the bias enabled.		
		1 : confirms if the port is the bias disabled.		
	biaschan_list[]	Channel numbers to know the bias status. 5 digits integer. ABCDE. where A: card number, BC: input port number, DE: output port number. Top zero(s) can be ignored. For example, if A=0, BC=01, and DE=01, channel number should be 101 instead of 00101.		
	bias_status[]	Bias status of the channels given in the biaschan_list. Returned value depends on the setting of bias_disen as shown below:		
		when bias_disen=0, 0 means bias disabled, 1 means enabled.		
		when bias disen=1, 0 means bias enabled, 1 means disabled.		

Driver Functions hpe5250a_biasPort

Parameters

hpe5250a_biasPort

This function will select which input port is the bias port on the specified card. For each card, you can specify the same or different Bias Port. This function applies only to the E5252A card.

Syntax ViStatus _VI_FUNC hpe5250a_biasPort(ViSession vi, ViInt16 biasport_cardno, ViInt16 bias_port);

vi Instrument handle returned from hpe525	0a_init().
---	-------------

- biasport_cardno Card number. 1 (card 1), 2 (card 2), 3 (card 3), 4 (card 4), or 5 (all card) in the normal configuration mode, or 0 (all card in the automatic configuration mode). For the configuration mode, see hpe5250a_func.
- bias_port Input port number to be set to the bias port. 1 to 10 (input port 1 to input port 10).

hpe5250a_biasState

This function controls the bias mode for the specified card. When Bias Mode is ON, the input Bias Port is connected to all bias enabled output ports that are not connected to any other input ports. Bias disabled output ports are never connected to the input Bias Port when Bias Mode is ON.

Syntax ViStatus_VI_FUNC hpe5250a_biasState(ViSession vi, ViInt16 biasstate_cardno, ViInt16 state);

ParametersviInstrument handle returned from hpe5250a_init().

biasstate_cardno Card number. 1 (card 1), 2 (card 2), 3 (card 3), 4 (card 4), or 5 (all card) in the normal configuration mode, or 0 (all card in the automatic configuration mode). For the configuration mode, see hpe5250a_func.

state Bias mode. 0 (OFF) or 1 (ON).
hpe5250a_close

	This function terminates the software connection to the instrument and deallocates system resources. It is generally a good programming habit to close the instrument handle when the program is done using the instrument.		
Syntax	ViStatus _VI_FUNC hpe5250a_close(ViSession vi);		
Parameters	vi	Instrument handle returned from hpe5250a_init().	
	hpe5250a_closeCard_Q		
	This function will query the card for the channels closed of the specified card.		
	The parameter 'closechan_list' contains the channel numbers returned by the instrument. This will be an array of integers terminated by 'zero' to identify the end of the list. Array of enough length should be passed to the function.		
Syntax	ViStatus _VI_FUNC hpe5250a_closeCard_Q(ViSession vi, ViInt16 close_card, ViInt32 _VI_FAR closechan_list[]);		
Parameters	vi	Instrument handle returned from hpe5250a_init().	
	close_card	Card number. 1 (card 1), 2 (card 2), 3 (card 3), or 4 (card 4) in the normal configuration mode, or 0 (all card in the automatic configuration mode). For the configuration mode, see hpe5250a_func.	
	closechan_list[]	Channels closed of the specified card.	

Driver Functions hpe5250a_closeList

hpe5250a_closeList

This function will connect the input ports to the output ports specified by the channel list.

The parameter 'closechan_list' is an array of integers with each integer representing one channel. The last number of the 'closechan_list' should be "0" (numeric zero) to identify the end of the list. The maximum number of channels that can be specified by the list is 100.

 Syntax
 ViStatus _VI_FUNC hpe5250a_closeList(ViSession vi, ViInt32_VI_FAR closechan_list[]);

Parameters vi Instrument handle returned from hpe5250a_init().

closechan_list[] Channel numbers to connect. 5 digits integer. ABCDE. where A: card number, BC: input port number, DE: output port number. Top zero(s) can be ignored. For example, if A=0, BC=01, and DE=01, channel number should be 101 instead of 00101.

hpe5250a_closeList_Q

	This function will 'closechan_list'.	query the instrument for the channels closed given in the		
	The parameter 'clo one channel. The l to identify the end specified by the list	The parameter 'closechan_list' is an array of integers with each integer representing one channel. The last number of the 'closechan_list' should be "0" (numeric zero) to identify the end of the list. The maximum number of channels that can be specified by the list is 100.		
	The 'close_status' parameter is an array of integers containing the return values of the query. The 'close_status' array returned will correspond one to one with 'closechan_list' parameter.			
Syntax	ViStatus _VI_FUN ViInt32_VI_FAR	ViStatus _VI_FUNC hpe5250a_closeList_Q(ViSession vi, ViInt32_VI_FAR closechan_list[], ViInt32_VI_FAR close_status[]);		
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	closechan_list[]	Channel numbers to know the close status. 5 digits integer. ABCDE. where A: card number, BC: input port number, DE: output port number. Top zero(s) can be ignored. For example, if A=0, BC=01, and DE=01, channel number should be 101 instead of 00101.		
	close_status[]	Status of the channels given in the closechan_list. 0 (opened) or 1 (closed).		
	hpe5250a_ci	md		
	This function passes the cmd_str string to the instrument. Must be a NULL			

terminated C string.

Syntax	ViStatus _VI_	ViStatus _VI_FUNC hpe5250a_cmd(ViSession vi, ViString cmd_str);	
Parameters	vi	Instrument handle returned from hpe5250a_init().	
	cmd_str	Instrument command (cannot exceed 256 bytes in length).	

Driver Functions hpe5250a_cmdData_Q

hpe5250a_cmdData_Q

This function passes the cmd_str string to the instrument. This entry point will wait for a response which may be any data. You specify the cmd_str and size parameters, and get result[].

Syntax ViStatus _VI_FUNC hpe5250a_cmdData_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViChar _VI_FAR result[]);

viInstrument handle returned from hpe5250a_init().cmd_strInstrument command (cannot exceed 256 bytes in length).sizeLength of result in bytes. 2 to 32767.result[]Response from instrument.

hpe5250a_cmdInt

Parameters

This function passes the cmd_str string to the instrument. This entry point passes the string in cmd_str followed by a space and then the integer in value. Note that either an Int16 or 32 can be passed as the Int16 will be promoted.

Syntax ViStatus_VI_FUNC hpe5250a_cmdInt(ViSession vi, ViString cmd_str, ViInt32 value);

Parameters	vi	Instrument handle returned from hpe5250a_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	value	Parameter for command2147483647 to 2147483647.

hpe5250a_cmdInt16Arr_Q

This function passes the cmd_str string to the instrument. This command expects a response that is a definite arbitrary block of 16 bit integers. You specify the cmd_str and size parameters, and get result[] and count.

Syntax ViStatus _VI_FUNC hpe5250a_cmdInt16Arr_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViInt16_VI_FAR result[], ViPInt32 count);

Parameters	vi	Instrument handle returned from hpe5250a_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	size	Size of result[] (number of items in the array). 1 to 2147483647.
	result[]	Response from instrument.
	count	Count of valid items in result].

hpe5250a_cmdInt16_Q

This function passes the cmd_str string to the instrument. This command expects a response that can be returned as a 16 bit integer.

SyntaxViStatus _VI_FUNC hpe5250a_cmdInt16_Q(ViSession vi, ViString cmd_str,
ViPInt16 result);ParametersviInstrument handle returned from hpe5250a init().

ameters	Vl	Instrument handle returned from hpe5250a_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	result	Response from instrument.

Driver Functions hpe5250a_cmdInt32Arr_Q

hpe5250a_cmdInt32Arr_Q

	This function paresponse that is and size parameters	This function passes the cmd_str string to the instrument. This command expects a response that is a definite arbitrary block of 32 bit integers. You specify the cmd_str and size parameters, and get result[] and count.		
Syntax	ViStatus _VI_F ViInt32 size, Vi	ViStatus _VI_FUNC hpe5250a_cmdInt32Arr_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViInt32 _VI_FAR result[], ViPInt32 count);		
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	cmd_str	Instrument command (cannot exceed 256 bytes in length).		
	size	Size of result[] (number of items in the array). 1 to 2147483647.		
	result[]	Response from instrument.		
	count	Count of valid items in result[].		
	hpe5250a_	hpe5250a_cmdInt32_Q		
	This function participation response that ca	This function passes the cmd_str string to the instrument. This command expects a response that can be returned as a 32 bit integer.		
Syntax	ViStatus _VI_F ViPInt32 result)	ViStatus _VI_FUNC hpe5250a_cmdInt32_Q(ViSession vi, ViString cmd_str, ViPInt32 result);		
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	cmd_str	Instrument command (cannot exceed 256 bytes in length).		

result Response from instrument.

hpe5250a_cmdReal

	This function the string in cr an Real32 or 6	passes the cmd_str string to the instrument. This entry point passes nd_str followed by a space and then the real in value. Note that either 54 can be passed as the Real32 will be promoted.		
Syntax	ViStatus _VI_ ViReal64 valu	ViStatus _VI_FUNC hpe5250a_cmdReal(ViSession vi, ViString cmd_str, ViReal64 value);		
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	cmd_str	Instrument command (cannot exceed 256 bytes in length).		
	value	Parameter for command1E+300 to 1E+300.		
	hpe5250a	hpe5250a_cmdReal64Arr_Q		
	This function passes the cmd_str string to the instrument. This com response that is a definite arbitrary block of 64 bit reals. You specif and size parameters, and get result[] and count.			
Syntax	ViStatus _VI_ ViInt32 size, V	ViStatus _VI_FUNC hpe5250a_cmdReal64Arr_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViReal64 _VI_FAR result[], ViPInt32 count);		
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	cmd_str	Instrument command (cannot exceed 256 bytes in length).		
	size	Size of result[] (number of items in the array). 1 to 2147483647.		
	result[]	Response from instrument.		
	count	Count of valid items in result].		

Driver Functions hpe5250a_cmdReal64_Q

Parameters

hpe5250a_cmdReal64_Q

This function passes the cmd_str string to the instrument. This command expects a response that can be returned as a 64 bit real.

Syntax ViStatus_VI_FUNC hpe5250a_cmdReal64_Q(ViSession vi, ViString cmd_str, ViPReal64 result);

viInstrument handle returned from hpe5250a_init().cmd_strInstrument command (cannot exceed 256 bytes in length).resultResponse from instrument.

hpe5250a_cmdString_Q

This function passes the cmd_str string to the instrument. This entry point will wait for a response which must be a string (character data). You specify the cmd_str and size parameters, and get result[].

 Syntax
 ViStatus _VI_FUNC hpe5250a_cmdString_Q(ViSession vi, ViString cmd_str, ViInt32 size, ViChar _VI_FAR result[]);

Parameters	vi	Instrument handle returned from hpe5250a_init().
	cmd_str	Instrument command (cannot exceed 256 bytes in length).
	size	Length of result in bytes. 2 to 32767.
	result[]	Response from instrument.

hpe5250a_compenC

	This function compensates capacitance/conductance data measured by using Agi- lent 4284A C meter, and returns compensation results. If you change the compensa- tion data, create the compensation data file, and specify the data file using hpe5250a_selectCompenFile function before executing this function.		
Syntax	ViStatus _VI_FUNC hpe5250a_compenC(ViSession vi,ViReal64 frequency, ViReal64 len_hptrx, ViReal64 len_usrtrx_h, ViReal64 len_usrtrx_l, ViReal64 len_usrcoax_h, ViReal64 len_usrcoax_l, ViReal64 raw_c, ViReal64 raw_g, ViPReal64 compen_c, ViPReal64 compen_g);		
Parameters	vi	Instrument handle returned from hpe5250a_init().	
	frequency	Measurement frequency. 1E3 to 1E6 Hz.	
	len_hptrx	Agilent 16494A triaxial cable. 1.5 or 3.0 m.	
	len_usrtrx_h	Triaxial cable length (in m) between connector plate and DUT high terminal. If you do not use triaxial cable, enter 0 (zero).	
	len_usrtrx_l	Triaxial cable length (in m) between connector plate and DUT low terminal. If you do not use triaxial cable, enter 0 (zero).	
	len_usrcoax_h	Coaxial cable length (in m) between connector plate and DUT high terminal. If you do not use coaxial cable, enter 0 (zero).	
	len_usrcoax_l	Coaxial cable length (in m) between connector plate and DUT low terminal. If you do not use coaxial cable, enter 0 (zero).	
	raw_c	Capacitance value (in F) measured by the 4284A.	
	raw_g	Conductance value (in S) measured by the 4284A.	
	compen_c	Capacitance compensation result (in F).	
	compen_g	Conductance compensation result (in S).	

Driver Functions hpe5250a_connRuleSeq

hpe5250a_connRuleSeq

The function sets connection rule and connection sequence for the specified card.

Syntax ViStatus _VI_FUNC hpe5250a_connRuleSeq(ViSession vi, ViInt16 cardno_ruleseq, ViInt16 rule, ViInt16 sequence);

Parameters

vi Instrument handle returned from hpe5250a_init().

- cardno_ruleseq Card number. 1 (card 1), 2 (card 2), 3 (card 3), 4 (card 4), or 5 (all card) in the normal configuration mode, or 0 (all card in the automatic configuration mode). For the configuration mode, see hpe5250a_func.
- rule Connection rule. 0 (free route) or 1 (single route).
- sequence Connection sequence. 0, 1, or 2. See below.
 - 0 (no sequence)
 - 1 (break before make)
 - 2 (make before break)

hpe5250a_couplePort

	This function sets the couple ports which are used for making kelvin connections on the specified card. The specified input port number will be coupled with the next input port and two output ports. For each card, you may setup the same or different couple ports. This command overwrites the previous couple port setting for the card. This command applies only to the E5252A card. The couple port mode is controlled by the hpe5250a_coupleState function	
Syntax	ViStatus _VI_FUNC hpe5250a_couplePort(ViSession vi, ViInt16 coupleport_cardno, ViInt16 port1, ViInt16 port3, ViInt16 port5, ViInt16 port7, ViInt16 port9);	
Parameters	vi	Instrument handle returned from hpe5250a_init().
	coupleport_cardno	Card number. 1 (card 1), 2 (card 2), 3 (card 3), 4 (card 4), or 5 (all card) in the normal configuration mode, or 0 (all card in the automatic configuration mode). For the configuration mode, see hpe5250a_func.
	portl	Couple port by the input ports 1 and 2. 0 (disable) or 1 (enable).
	port3	Couple port by the input ports 3 and 4. 0 (disable) or 1 (enable).
	port5	Couple port by the input ports 5 and 6. 0 (disable) or 1 (enable).
	port7	Couple port by the input ports 7 and 8. 0 (disable) or 1 (enable).
	port9	Couple port by the input ports 9 and 10. 0 (disable) or 1 (enable).

Driver Functions hpe5250a_coupleState

hpe5250a_coupleState

This function controls the couple port mode for the specified card. This function applies only to the E5252A card.

Syntax ViStatus _VI_FUNC hpe5250a_coupleState(ViSession vi, ViInt16 couplestate_cardno, ViInt16 couple_state);

Parameters

vi Instrument handle returned from hpe5250a_init(). couplestate_cardno Card number. 1 (card 1), 2 (card 2), 3 (card 3), 4 (card 4), or 5 (all card) in the normal configuration mode, or 0 (all card in the automatic configuration mode). For the configuration mode, see hpe5250a func.

couple_state Couple port mode. 0 (OFF) or 1 (ON).

hpe5250a_dcl

This function sends a device clear (DCL) to the instrument.

A device clear will abort the present operation and enable the instrument to accept a new command or query.

This is particularly useful in situations where it is not possible to determine the instrument state. In this case, it is customary to send a device clear before issuing a new instrument driver function. The device clear ensures that the instrument will be able to begin processing the new commands.

Syntax ViStatus_VI_FUNC hpe5250a_dcl(ViSession vi);

ParametersviInstrument handle returned from hpe5250a_init().

hpe5250a_error_message

This function translates the error return value from an instrument driver function to a readable string.

Syntax ViStatus _VI_FUNC hpe5250a_error_message(ViSession vi, ViStatus error_number, ViChar _VI_FAR message[]);

Parameters	vi	Instrument handle returned from hpe5250a_init().
	error_number	Error return value from the driver function.
	message[]	Error message string. This is limited to 256 characters.

hpe5250a_error_query

This function returns the error numbers and corresponding error messages in the error queue of a instrument. See Agilent E5250A *User's Guide* for a listing of the instrument error numbers and messages.

Instrument errors may occur when you places the instrument in a bad state such as sending an invalid sequence of coupled commands. Instrument errors can be detected by polling. Automatic polling can be accomplished by using the hpe5250a errorQueryDetect function.

 Syntax
 ViStatus _VI_FUNC hpe5250a_error_query(ViSession vi, ViPInt32 error_number, ViChar _VI_FAR error_message[]);

Parameters	vi	Instrument handle returned from hpe5250a_init().
	error_number	Instrument's error code.
	error_message[]	Instrument's error message. This is limited to 256 characters.

Driver Functions		
hpe5250a_errorQueryDetect		

hpe5250a_errorQueryDetect

This function enables or disables automatic instrument error checking.

If automatic error checking is enabled then the driver will query the instrument for an error at the end of each function call.

Syntax	ViStatus _VI_FUNC hpe5250a_errorQueryDetect(ViSession vi,
	ViBoolean errorQueryDetect);

ParametersviInstrument handle returned from hpe5250a_init().

errorQueryDetect Error checking enable (VI_TRUE) or disable (VI_FALSE).

hpe5250a_errorQueryDetect_Q

This function indicates if automatic instrument error detection is enabled or disabled.

Syntax ViStatus_VI_FUNC hpe5250a_errorQueryDetect_Q(ViSession vi, ViPBoolean pErrDetect);

Parameters vi Instrument handle returned from hpe5250a_init().

pErrDetect Error checking enable (VI_TRUE) or disable (VI_FALSE).

hpe5250a_esr_Q

This function returns the contents of the ESR register. The driver returns the equivalent messages (see Parameters).

Syntax	ViStatus _VI_FUNC hpe5250a_esr_Q(ViSession vi, ViChar _VI_FAR errstr[]);		
Parameters	vi Instrument handle returned from hpe5250a_init().		
	errstr[]	Response from ins	strument.
		Bit Value	Message
		1	"ESR_OPC"
		2	"ESR_RQL"
		4	"ESR_QYE_ERROR"
		8	"ESR_DEVICE_DEPENDENT_ERROR"
		16	"ESR_EXECUTION_ERROR"
		32	"ESR_COMMAND_ERROR"
		64	"ESR_URQ"
		128	"ESR_PON"
		OTHERS	"ESR_MULTI_EVENT"

hpe5250a_func

This function is used to set the channel configuration to the auto configuration mode or the normal configuration mode.

Syntax	ViStatus _VI_FUNC hpe5250a_func(ViSession vi, ViInt16 channel_config);		
Parameters	vi Instrument handle returned from hpe5250a_ini		
	channel_config	Configuration mode. 0 (auto) or 1 (normal).	

Driver Functions hpe5250a_init

hpe5250a_init

	This function i verifies that ins actions to place	nitializes the software connection to the instrument and optionally strument is in the system. In addition, it may perform any necessary e the instrument in its reset state.	
	If the hpe5250 parameter will	a_init function encounters an error, then the value of the vi output be VI_NULL.	
Syntax	ViStatus _VI_I ViBoolean do_	FUNC hpe5250a_init(ViRsrc InstrDesc, ViBoolean id_query, reset, ViPSession vi);	
Parameters	InstrDesc	Instrument description. Examples; GPIB0::1::INSTR.	
	id_query	VI_TRUE (to perform In-System Verification), or VI_FALSE (do not perform In-System Verification).	
	do_reset	VI_TRUE (to perform reset operation), or VI_FALSE (do not perform reset operation).	
	vi	Instrument handle. This is VI_NULL if an error occurred during the init.	
	hpe5250a_opc_Q		
	This function does the *OPC? common command.		
Syntax	ViStatus _VI_I	ViStatus _VI_FUNC hpe5250a_opc_Q(ViSession vi, ViPBoolean result);	
Parameters	vi	Instrument handle returned from hpe5250a_init().	
	result	VI_TRUE (Operation complete), or VI_FALSE (Operation is pending).	

hpe5250a_openCard

This function will disconnect all input ports from all output ports for the specified card. Then if bias mode is ON, connects the input bias port to all bias enabled output ports.

Syntax	ViStatus _VI_FU	ViStatus _VI_FUNC hpe5250a_openCard(ViSession vi, ViInt16 open_cardno);			
Parameters	vi	Instrument handle returned from hpe5250a_init().			
	open_cardno	Card number. 1 (card 1), 2 (card 2), 3 (card 3), 4 (card 4), or 5 (all card) in the normal configuration mode, or 0 (all card in the automatic configuration mode). For the configuration mode, see hpe5250a_func.			
	hpe5250a_	hpe5250a_openList			
	This function wi channel list.	This function will disconnect the input ports from the output ports specified by the channel list.			
	The parameter 'd one channel. The to identify the er specified by the	The parameter 'openchan_list' is an array of integers with each integer representing one channel. The last number of the 'openchan_list' should be "0" (numeric zero) to identify the end of the list. The maximum number of channels that can be specified by the list is 100.			
Syntax	ViStatus _VI_FU ViInt32_VI_FAI	ViStatus _VI_FUNC hpe5250a_openList(ViSession vi, ViInt32_VI_FAR openchan_list[]);			
Parameters	vi	Instrument handle returned from hpe5250a_init().			
	openchan_list[]	Channel numbers to disconnect. 5 digits integer. ABCDE. where A: card number, BC: input port number, DE: output port number. Top zero(s) can be ignored. For example, if A=0, BC=01, and DE=01, channel number should be 101 instead of 00101.			

Driver Functions hpe5250a_openList_Q

hpe5250a_openList_Q

	This function will 'openchan_list'.	query the instrument for the channels open given in the	
	The parameter 'ope one channel. The la to identify the end specified by the lis	enchan_list' is an array of integers with each integer representing ast number of the 'openchan_list' should be "0" (numeric zero) of the list. The maximum number of channels that can be t is 100.	
	The 'open_status' the query. The 'open 'openchan_list' pa	parameter is an array of integers containing the return values of en_status' array returned will correspond one to one with rameter.	
Syntax	ViStatus _VI_FUNC hpe5250a_openList_Q(ViSession vi, ViInt32_VI_FAR openchan_list[], ViInt32_VI_FAR open_status[]);		
Parameters	vi	Instrument handle returned from hpe5250a_init().	
	openchan_list[]	Channel numbers to know the open status. 5 digits integer. ABCDE. where A: card number, BC: input port number, DE: output port number. Top zero(s) can be ignored. For example, if A=0, BC=01, and DE=01, channel number should be 101 instead of 00101.	
	open_status[]	Status of the channels given in the openchan_list. 1 (opened) or 0 (closed).	
	hpe5250a_readStatusByte_Q		
	This function retur	ns the contents of the status byte register.	
Syntax	ViStatus _VI_FUNC hpe5250a_readStatusByte_Q(ViSession vi, ViPInt16 statusByte);		
Parameters	vi	Instrument handle returned from hpe5250a_init().	
	statusByte	The contents of the status byte are returned in this parameter.	

hpe5250a_reset

	This function pla may be necessar reset. A device	aces the instrument in a default state. Before issuing this function, it y to send a device clear to ensure that the instrument can execute a clear can be issued by invoking hpe5250a_dcl function.		
Syntax	ViStatus _VI_FU	ViStatus _VI_FUNC hpe5250a_reset(ViSession vi);		
Parameters	vi	vi Instrument handle returned from hpe5250a_init().		
	hpe5250a_revision_query			
	This function ret	This function returns the driver revision and the instrument firmware revision.		
Syntax	ViStatus _VI_FU ViChar_VI_FAR	ViStatus _VI_FUNC hpe5250a_revision_query(ViSession vi, ViChar_VI_FAR driver_rev[], ViChar _VI_FAR instr_rev[]);		
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	driver_rev[]	Instrument driver revision. This is limited to 256 characters.		
	instr_rev[]	Instrument firmware revision. This is limited to 256 characters.		

Driver Functions hpe5250a_selectCompenFile

hpe5250a_selectCompenFile

This function specifies capacitance/conductance compensation data file used to compensate C/G by using hpe5250a_compenC.

Syntax ViStatus_VI_FUNC hpe5250a_selectCompenFile(ViSession vi, ViString file_name);

Parameters	vi	Instrument handle returned from hpe5250a_init().
	file_name	Compensation data file name. Use absolute path. If the value is
		NULL string, the default data is used.

Remarks If you change the compensation data, copy the default data shown below, and modify the data for your measurement cable. You will need to change the data for DATA05 and 06, and/or DATA07 and 08 corresponding to your cables. To measure and change the compensation data, refer to Agilent E5250A *User's Guide*. To get the R, L, and C value, measure R, L, and C of the cable using the 4284A, and divide them by cable length (in m). Compensation data must be the value for 1 m length. Do not change the data format in the file.

# E5250A C Compensation coefficient data table #				
# CAUTION :	Do not add or	delete "REVIS	ION" line and	"DATAxx" line.
#	Change the va	lue for R,L,C	of DATA05,06,0	7 or 08.
#				
REVISION	A. 03. 00			
#	R [ohm]	L [H]	C [F]	
DATAOO	74. 65E-3	140.00E-9	58. 44E-12	# Frame Path 1
DATA01	75. 41E-3	90.00E-9	67.13E-12	# Frame Path 2
DATA02	231.41E-3	450.00E-9	178.85E-12	# Card Path High
DATA03	177.56E-3	390.00E-9	135. 45E-12	# Card Path Low
DATA04	100.70E-3	400.00E-9	80.00E-12	# Triax Cable [/m]
DATA05	100.70E-3	400.00E-9	80.00E-12	# User Triax Cbl H [/m]
DATA06	100.70E-3	400.00E-9	80.00E-12	# User Triax Cbl L [/m]
DATA07	114.00E-3	544.00E-9	130.00E-12	# User Coax Cbl H [/m]
DATA08	114.00E-3	544.00E-9	130.00E-12	# User Coax Cbl L [/m]
DATA09	0.00E-3	0.00E-9	1.20E-12	# Stray Capacitance
# END of Data				

hpe5250a_self_test

This function causes the instrument to perform a self-test and returns the result of that self-test. This is used to verify that an instrument is operating properly. A failure may indicate a potential hardware problem.

 Syntax
 ViStatus_VI_FUNC hpe5250a_self_test(ViSession vi, ViPInt16 test_result, ViChar_VI_FAR test_message[]);

Parameters	vi	Instrument handle returned from hpe5250a_init().
	test_result	Numeric result from self-test operation. 0: No error.
	test_message[]	Self-test status message. This is limited to 256 characters.

hpe5250a_testClear

Syntax

This function clears the test result for the specified relay card or the front panel or the controller.

ViStatus VI FUNC hpe5250a testClear(ViSession vi, ViInt16 framecard clear);

Parameters	vi	Instrument handle returned from hpe5250a_init().
	framecard_clear	Test result to be cleared. 0, 1, 2, 3, 4, 5, 6, or 7. See below.
		0 (test result of all test)
		1 (card 1 relay test result)
		2 (card 2 relay test result)
		3 (card 3 relay test result)
		4 (card 4 relay test result)
		5 (relay test result of all card)
		6 (front panel test result)
		7 (controller test result)

Driver Functions hpe5250a_testExec_Q

hpe5250a_testExec_Q

	This function exect specified card. You The Front Panel tes will fail.	ttes the controller test, the front panel test, or the relay test for the must attach the relay test adapter before executing the relay test. It requires the key to be pressed within 10 seconds else the test		
Syntax	ViStatus _VI_FUNC hpe5250a_testExec_Q(ViSession vi, ViInt16 framecard_exec, ViPInt16 exec_result);			
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	framecard_exec	Test to be executed. 1 (card 1 relay test) to 4 (card 4 relay test), 5 (relay test for all card), 6 (front panel test), or 7 (controller test).		
	exec_result	Test result. 0: No error.		
	hpe5250a_tir	neOut		
	This function sets a milliseconds. The c	minimum timeout value for driver I/O transactions in lefault timeout period is 2 seconds.		
Syntax	ViStatus_VI_FUNG	C hpe5250a_timeOut(ViSession vi, ViInt32 timeOut);		
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	timeOut	I/O timeout value for all functions in the driver. in milliseconds. 0 to 2147483647.		
	hpe5250a_timeOut_Q			
	This function return	ns the timeout value for driver I/O transactions in milliseconds.		
Syntax	ViStatus_VI_FUNG	C hpe5250a_timeOut_Q(ViSession vi, ViPInt32 pTimeOut);		
Parameters	vi	Instrument handle returned from hpe5250a_init().		
	pTimeOut	Minimum timeout period that the driver can be set to, in milliseconds.		

3 Programming Examples Using HP VEE

Programming Examples Using HP VEE

This chapter describes how to create measurement programs using HP VEE and the VXI*plug&play* driver for Agilent 4155B/4156B, and provides programming examples.

This chapter contains the following sections:

- "Programming Basics"
- "High-Speed Spot Measurements"
- "Multi-Channel Spot Measurements"
- "Staircase Sweep Measurements"
- "Synchronous Sweep Measurements"
- "Multi-Channel Sweep Measurements"
- "Pulsed Spot Measurements"
- "Multi-Channel Pulsed Spot Measurements"
- "Pulsed Sweep Measurements"
- "Multi-Channel Pulsed Sweep Measurements"
- "Staircase Sweep with Pulsed Bias Measurements"
- "Sampling Measurements"
- "Stress Force"

Programming Basics

This section covers the following topics.

- "Registrating the Driver on HP VEE"
- "Basic Objects to Control the Instrument"
 - "To display the To/From object"
 - "To define transactions in the To/From object"
 - "To set input parameters"
 - "To use the Help function"
 - "To use input variables"
 - "To create output terminals in the To/From object"
 - "To display/connect the Data object"
 - "To display/connect the Display object"
- "Debugging Your Program"
- "Restrictions When Using the Driver with HP VEE"

Registrating the Driver on HP VEE

To use the VXI*plug&play* driver on HP VEE, register the driver as described below and as shown in Figure 3-1 on page 3-5.

- 1. Click the I/O menu.
- 2. Select Instrument Manager from the I/O menu. The Instrument Manager dialog box is displayed. The dialog box lists the available devices (instruments). If this is the first time using HP VEE, only off-line (NOT LIVE) devices are shown in the Instrument List.
- 3. Click Add. The Device Configuration dialog box is displayed.
- 4. Enter the device name in the Name field. The example shown in Figure 3-1 sets "HP4156B".
- 5. Enter the GPIB address for the device in the Address field. The example shown in Figure 3-1 sets "717".
- 6. Click Advanced I/O Config. The Advanced Device Configuration dialog box is displayed.
- 7. Click the Plug&play Driver tab.
- Select HP4156B in the Plug&play Driver Name field to configure the 4155B/4156B driver. If the driver is not installed properly, "HP4156B" is not available in this field. Install the driver properly at this time.
- 9. Click OK to close the Advanced Device Configuration dialog box.
- 10. Click OK to close the Device Configuration dialog box.
- 11. Click Save Config to save the configuration of the drivers. The Instrument Manager dialog box is closed.

You can now use the VXIplug&play driver for the 4155B/4156B.

File Edit View		HP	Z					V A
	► III ■	Instrument Manager			\square			
Untitled		Inscriment Panager Advanced I/O Bus I/O Monitor ent Manager ment List configuration HP-IB0 hPF20c(@(NOT LIVE)) HP-IB7 dmm(hp34401a@(NOT LIVE)) Serial9 serial(@(NOT LIVE))		Configuration Add Delete Edit Get Device Direct I/ Plug&play D Panel Driv Component I	×	3		
11 -	Advan Gen Plugspi Address ØPer	Save Config Cancel ccd Device Configuration eral Direct I/O Pilu Isy Driver Name: ter to Init) Call (eg OPIB-VXI:12:INSTR): GPIB form Reset 9	Help Help HP41 HP41568 Unknown HP5isa Unknown Help	× Panel Driver 56B V BA	-7 -8 Add Gat	Device Conf me: rface: ifress(eq714): eway: Advanced I/O (OK Canc	iguration HP41568 HP-IB 717 This host Config el Help	

Figure 3-1 Registering the Driver on HP VEE

Basic Objects to Control the Instrument

You can create programs using HP VEE and the VXI*plug&play* driver, as shown in the following steps. In this procedure you use only three objects; To/From, Data, and Display, shown in Figure 3-2.

- 1. Display the To/From object for the VXI*plug&play* driver.
- 2. Define the transactions (functions of the driver) in the To/From object.
- 3. Set the input parameters for the transaction.
- 4. (Optional: Use a variable for the input parameter.)
- 5. Repeat steps 2, 3, and 4 to complete the To/From object.
- 6. Connect the input terminals of the To/From object to the Data object.
- 7. Connect the output terminals of the To/From object to the Display object.
- 8. Complete the HP VEE program.

Figure 3-2 Basic Objects of HP VEE



The To/From HP4156B object, in Figure 3-2, defines the following transactions (functions of the *plug&play* driver) to measure the current flow to a resistor.

hp4156b_setSwitch	This function controls the 4155B/4156B output switch.
hp4156b_force	This function forces dc voltage or current.
hp4156b_spotMeas	This function executes a spot measurement.
hp4156b zeroOutput	This function disables the 4155B/4156B output.

To display the To/From object

You can display the To/From object as shown below.

- 1. Click I/O menu.
- 2. Select Instrument Manager to display the Instrument Manager dialog box.
- 3. Select HP4156B in the Instrument List.
- 4. Click Plug&play Driver.

The Instrument Manager dialog box is then closed, and the To/From HP4156B object will be displayed by moving the mouse pointer to the appropriate point, then clicking the left mouse button.

Figure 3-3 To Display the To/From Object



To define transactions in the To/From object

You can define transactions (functions of *plug&play* driver) as shown in the following example.

- 1. Double click the blue stripe on the To/From object. The Select a Function Panel dialog box is displayed. The dialog box lists the functions available for the instrument, and displays the Help message for the selected function.
- 2. Select the function you want to add to the To/From object. Figure 3-4 selects the "Applying dc Current/Voltage" function, and displays the Help message for that function.
- 3. Click OK. The Select a Function Panel dialog box is closed, and the Edit Function Panel dialog box is displayed. See Figure 3-5 on page 3-9.





NOTE

To add, insert, cut, copy, or paste the transaction, click the right mouse button on the To/From object, then select Add Trans, Insert Trans, Cut Trans, Copy Trans, or Paste Trans.

To set input parameters

You can set the input parameter value using the Edit Function Panel dialog box. Figure 3-5 sets the following values for the input parameters of the hp4156b_force function, which forces dc current or voltage.

channel	SMU1
mode	VOLTAGE OUTPUT
range (output range)	0 (auto range)
value	0 V
compliance	10 mA
polarity	AUTO

Figure 3-5 To Set Input Parameters



Programming Examples Using HP VEE Programming Basics

To use the Help function

If you need to know the details for each parameter in order to enter the parameter value, move the mouse pointer to the appropriate entry field, then click the right mouse button. The context-based Help function will be displayed. Figure 3-6 shows the Help message for the *comp* entry field.



MP VEE				_ 8 ×
<u>File Edit View Debug Flow Dev</u>	rice [/O Daţa Di <u>s</u> play <u>W</u> indow <u>H</u> elp			
1 🖆 🖬 🎒 🛛 🕨 🗉	1998년 1886년 18	🛤 🖬 🔊 🏊 👗 🖻 🛍 📲 🛣 🖺	. 0	
	🖥 Main		_	_ 8 ×
⊠ Unfiled └─ 🗟 Main	Help for control comp Compliance value (only for SMU) If the input comp value is out parameter and polarity paramete For voltage compliance: -200 V For current compliance: -1.0 A Data Type: ViReal64 Input/Output: IN Value: Value:	of the following range, comp r are ignored. to 200 V to 1.0 A	Para Para	ameters Trange
	Name Value hp4156b_SHUV_HIN -200.0 hp4156b_SHUV_HAX 200.0		COMPUT - I	polarity AUTO - MANUAL -
	Click right button —	vi 0 hp4156b_force(instrHandle, hp4156b_CH_ hp4156b_POL_AUTO) OK h	SMU1, hp4156b_VF_MODE, 0, I	Error #H0
Ready				VEEN FROF MOD

NOTE

To open on-line Help for the *plug&play* driver, click the right mouse button in the To/From object, then select "Instrument Help".

To use input variables

Most of the Edit Function Panel dialog boxes have two tabs, Panel and Parameters. To change the value, enter the value in the Panel tab.

If you pass the value from another object, such as Data-Real object, click the Parameters tab, and use Variable (not Constant). See Figure 3-7.



Figure 3-7To Use Input Variables

NOTE

You can add terminals, after closing the dialog box, by placing the mouse pointer on the terminal area in the object and pressing Ctrl-A. You can also delete terminals by placing the mouse pointer on the terminal name you want to delete, and pressing Ctrl-D.

To create output terminals in the To/From object

Figure 3-8 shows the Edit Function Panel dialog box of the hp4156b_spotMeas function. These measurement transactions need the output terminals in the To/From object. You can create the output terminal as shown in the following example.

- 1. Click the Parameters tab.
- 2. Enter the Name (output terminal name) for the output variable *value*.
- 3. Enter the Name (output terminal name) for the output variable *status*.
- 4. Click OK. The dialog box is closed, the transaction is added to the To/From object, and the output terminals are created in the object.

The output terminal will be created with the default name if steps 2 and 3 are omitted.

- a wain		To/From HP4156	3B	
		Edit Function Panel for hp4156b_spotMeas()	Parameter	
		Parameter Type: Constant Variable Name: bp.4156b CH SMI11		
		mode Parameter Type:		
		Name: hp415bb_VM_MOUE range Parameter Type: Constant Variable Name: 0	Create Input I erminal	
	2	value Parameter Type:	🔽 Create Output Terminal	
		Status Parameter Type: < Constant & Variable Name: Status	🔽 Create Output Terminal	

Figure 3-8To Create Output Terminals

To display/connect the Data object

In Figure 3-9, the Data-Real object is used to pass the input parameter value to the *value* input variable of the hp4156b_force transaction.

You can display the Data-Real object by clicking the Data menu, selecting Constant, and then selecting Real. To pass the value, connect the output terminal of the Data-Real object to the input terminal of the To/From HP4156B object.

NOTE Confirm the data type of the input variable. The data type of the Data object must be the same as the data type for the input parameter.

To display/connect the Display object

In Figure 3-9, the Display-AlphaNumeric object is used to display the measurement data (*result* output variable) from the hp4156b spotMeas transaction.

You can display the Display-AlphaNumeric object by clicking the Display menu, and selecting AlphaNumeric. To display the value, connect the output terminal of the To/From HP4156B object to the input terminal of the Display-AlphaNumeric object.

Figure 3-9 To Connect Input/Output Terminals



Debugging Your Program

You may encounter problems when creating programs to control the 4155B/4156B. In the program development or debugging phase, insert the following transactions (functions of the driver) in the To/From object. Do not forget to remove the functions after completing the program. These functions will cause increased program execution time.

- hp4156b cmd(instrHandle,"US")
- hp4156b errorQueryDetect

To recover control mode

When using HP VEE, the 4155B/4156B control mode is controlled by the hp4156b init function, which is automatically called and executed by HP VEE when the program first runs after loading.

However, if you press any PAGE CONTROL key or LOCAL softkey on the 4155B/4156B front panel after program execution, the control mode is changed. Also, if an unexpected I/O error has occurred, you may need to do a hardware reset which changes the control mode. Once the control mode is changed, the program cannot run without reloading it.

To recover the control mode without reloading the program, enter the US command using the hp4156b cmd function as shown in Figure 3-10. The command recovers the effective control mode for the *plug&play* driver.



To Enter the US Command
To check for instrument error

The hp4156b_errorQueryDetect function enables or disables automatic instrument error checking. If automatic error checking is enabled, the driver will query the instrument for an error at the end of each function call.

If this function is enabled (1 of Figure 3-11) and if an error occurs in the function call, HP VEE stops the program execution and displays an error dialog box. You must then enter the hp4156b_error_query function (see 2 of Figure 3-11). The hp4156b error query function returns the instrument error code and error message.

In this example, an error occurred in the hp4156b_force function call. The cause of the error was an improper parameter setting for the hp4156b_setSwitch function.

Figure 3-11 To Use the hp4156b_error_query Function



Restrictions When Using the Driver with HP VEE

When using HP VEE and any of the following functions for Agilent 4155B/4156B and Agilent E5250A, certain restrictions will apply.

Invalid functions in the VEE program

• hp4156b_init, hpe5250a_init

HP VEE calls and executes these functions automatically when the program first runs after loading. These functions cannot be called in a program using HP VEE.

• hp4156b_close, hpe5250a_close

HP VEE calls and executes these functions automatically when you close the program or HP VEE. These functions cannot be called in a program using HP VEE.

• hp4156b_error_message, hpe5250a_error_message

These functions receive the error status of the plug&play driver function, and returns the error message. However, these functions are invalid in a program using HP VEE, because HP VEE does not pass the error status to the function.

Invalid use of the NULL pointer

The measurement functions listed below allow you to use the NULL pointer to restrict the number of parameters returned from the function. However, the NULL pointer is not available for HP VEE programming.

- hp4156b_spotMeas
- hp4156b_sweepIv
- hp4156b_sweepMiv
- hp4156b_sweepPiv
- hp4156b_sweepPbias
- hp4156b_measureM
- hp4156b_measureP
- hp4156b_sample
- hp4156b_readData

High-Speed Spot Measurements

To make high-speed spot measurements, use the following functions.

Table 3-1 Functions for High-Speed Spot Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Executes measurement	hp4156b_spotMeas	channel,mode,range,value,status
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-13 on page 3-18. This program measures MOSFET drain current. The measurement setup is shown in Figure 3-12.

Figure 3-12 Device Connection and Source Setup for Example Program







Table 3-2	Program	Explanation
	1 logi am	Daplanation

Object Title	Menu	Explanation
Vs,Vg,Vsub,Vd	Data-Constant-Real	Enters input parameters of hp4156b_force.
To/From HP4156B	I/O-InstrumentManager-Plug&play	Executes measurement.
Drain Current	Display-AlphaNumeric	Displays Id. (hp4156b_spotMeas value parameter)
Status	Display-AlphaNumeric	Displays status. (hp4156b_spotMeas status parameter)

Multi-Channel Spot Measurements

To make multi-channel spot measurements, use the following functions.

Table 3-3 Functions for Multi-Channel Spot Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Executes measurement	hp4156b_measureM	channel[],mode[],range[],value[],status[]
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-15 on page 3-20. This program measures bipolar transistor collector current and base current. The example uses the User object of the HP VEE. See Figure 3-16 on page 3-21. The measurement setup is shown in Figure 3-14.

Figure 3-14







Table 3-4Program Explanation

Object Title	Menu	Explanation
Vbe	Data-Constant-Real	Enters input parameters of hp4156b_force.
To/From HP4156B	I/O-InstrumentManager-Plug&play	Executes measurement.
GetValues	Data-AccessArray-GetValues	Gets data from Array (value[], status[]).
IcStatus,Ic, IbStatus,Ib	Display-AlphaNumeric	Displays measurement data/status. (hp4156b_measureM output parameters)



Figure 3-16 SetArrayPara User Object

Table 3-5Program Explanation

Object Title	Menu	Explanation
Channels,Ch1,Ch2, Ch1Mode,Ch2Mode, Ch1Range,Ch2Range	Data-Constant-Integer Data-Constant-Real	Enters data to allocate array, and array element for channel[], mode[], range[] of hp4156b_measureM.
A+1	Device-Formula	Calculates A+1 to allocate array.
AllocReal, AllocInteger	Data-AllocateArray-Real Data-AllocateArray-Integer	Allocates array for channel[], mode[], range[] of hp4156b_measureM.
a[0]=b, a[1]=b	Data-AccessArray-SetValues	Sets data of array (array element).

Staircase Sweep Measurements

To make staircase sweep measurements, use the following functions.

Table 3-6 Functions for Staircase Sweep Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Sweep Source Setup	hp4156b_setIv	channel,mode,range,start,stop,point,hold,delay, s_delay,comp,p_comp
Executes measurement	hp4156b_sweepIv	channel,mode,range,point,source[],value[], status[]
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-18 on page 3-23. This program measures MOSFET Id-Vd characteristics. The measurement setup is shown in Figure 3-17.

Figure 3-17





Figure 3-18 Program Example of Staircase Sweep Measurement

Table 3-7Program Explanation

Object Title	Menu	Explanation
Vs,Vg,Vsub VdStart,VdStop MeasPoints	Data-Constant-Real Data-Constant-Integer	Enters input parameters of hp4156b_force, hp4156b_setIv, and hp4156b_sweepIv.
To/From HP4156B	I/O-InstrumentManager- Plug&play	Executes measurement.
AllocReal	Data-AllocateArray-Real	Allocates array for Vd[],Id[],status[] of hp4156b_sweepIv.
Status Code	Display-AlphaNumeric	Displays status[].
Id-Vd Curve	Display-XvsYPlot	Plots Id-Vd curve.

Synchronous Sweep Measurements

To make synchronous sweep measurements, use the following function with the functions shown in "Staircase Sweep Measurements" on page 22, or "Pulsed Sweep Measurements" on page 34.

The hp4156b_setSweepSync function must be placed after the hp4156b_setIv function or the hp4156b_setPiv function in the To/From object.

 Table 3-8
 Function for Synchronous Sweep Measurements

Description	Function	Parameters
Synchronous Source Setup	hp4156b_setSweepSync	channel,mode,range,start,stop,comp, p_comp

A program example is shown in Figure 3-20 on page 3-25. This program measures MOSFET Id-Vg characteristics. The measurement setup is shown in Figure 3-19.

Figure 3-19 Device Connection and Source Setup for Example Program





Figure 3-20 Program Example of Synchronous Sweep Measurement

Table 3-9Program Explanation

Object Title	Menu	Explanation
Vs,Vsub Vstart,Vstop MeasPoints	Data-Constant-Real Data-Constant-Integer	Enters input parameters of hp4156b_force, hp4156b_setIv, and hp4156b_setSweepSync.
To/From HP4156B	I/O-InstrumentManager- Plug&play	Executes measurement.
AllocReal	Data-AllocateArray-Real	Allocates array for Vg[],Id[],status[] of hp4156b_sweepIv.
Status Code	Display-AlphaNumeric	Displays status[].
Id-Vg Curve	Display-XvsYPlot	Plots Id-Vg curve.

Multi-Channel Sweep Measurements

To make multi-channel sweep measurements, use the following functions.

Table 3-10	Functions for Multi-Channel Sweep) Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Sweep Source Setup	hp4156b_setIv	channel,mode,range,start,stop,point,hold,delay, s_delay,comp,p_comp
Executes measurement	hp4156b_sweepMiv	channel[],mode[],range[],point,source[], value[], status[]
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-22 on page 3-27. This program measures bipolar transistor Ic, Ib-Vbe characteristics. The example uses the User Object of the HP VEE. See Figure 3-23 on page 3-28 and Figure 3-24 on page 3-29. The measurement setup is shown in Figure 3-21.







Figure 3-22 Program Example of Multi-Channel Sweep Measurement

Table 3-11Program Explanation

Object Title	Menu	Explanation
VeStart,VeStop MeasPoints	Data-Constant-Real Data-Constant-Integer	Enters input parameters of hp4156b_setIv and hp4156b_sweepMiv.
To/From HP4156B	I/O-InstrumentManager-Plug&play	Executes measurement.
abs(x)	Device-Formula	Calculates absolute value of Vbe (source).
Ic,Ib-Vbe Curve	Display-XvsYPlot	Plots Ic-Vbe and Ib-Vbe curves.

Programming Examples Using HP VEE Multi-Channel Sweep Measurements





Table 3-12Program Explanation

Object Title	Menu	Explanation
Channels,Ch1,Ch2, Ch1Mode,Ch2Mode, Ch1Range,Ch2Range	Data-Constant-Integer Data-Constant-Real	Enters data to allocate array, and array element for channel[], mode[], range[] of hp4156b_sweepMiv.
A+1	Device-Formula	Calculates A+1 to allocate array.
AllocReal, AllocInteger	Data-AllocateArray-Real Data-AllocateArray-Integer	Allocates array for channel, mode, range, source, value, status of hp4156b_sweepMiv.
a[0]=b, a[1]=b	Data-AccessArray-SetValues	Sets data of array (array element).



Figure 3-24 GetMeasData User Object

Table 3-13Program Explanation

Object Title	Menu	Explanation
GetValues	Data-AccessArray-GetValues	Gets data from array (value[],status[]).
Ic/Ib	Device-Formula	Calculates a/b to get hFE value.
abs(x)	Device-Formula	Calculates absolute value of Ic, Ib, hFE.

Pulsed Spot Measurements

To make pulsed spot measurements, use the following functions.

Table 3-14 Functions for Pulsed Spot Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state (pulse channel must be set to OFF)
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Forces pulse bias	hp4156b_setPbias	channel,mode,range,base,peak,width,period, hold,compliance
Executes measurement	hp4156b_measureP	channel,mode,range,value,status
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-26 on page 3-31. This program measures MOSFET drain current. The measurement setup is shown in Figure 3-25.

Figure 3-25





Figure 3-26 Program Example of Pulsed Spot Measurement

Table 3-15Program Explanation

Object Title	Menu	Explanation
Vs,Vg,Vsub,Vd	Data-Constant-Real	Enters input parameters of hp4156b_force, and hp4156b_setPbias.
To/From HP4156B	I/O-InstrumentManager-Plug&play	Executes measurement.
Drain Current	Display-AlphaNumeric	Displays Id (hp4156b_measureP value parameter).
Status	Display-AlphaNumeric	Displays status (hp4156b_measureP status parameter).

Multi-Channel Pulsed Spot Measurements

To make multi-channel pulsed spot measurements, use the following functions.

 Table 3-16
 Functions for Multi-Channel Pulsed Spot Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state (pulse channel must be set to OFF)
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Sends Command String	hp4156b_cmd	command (PT and PV commands are sent)
Executes measurement	hp4156b_startMeasure	meas_type,channel[],mode[],range[],source
Disables output	hp4156b_zeroOutput	channel
Reads measurement data	hp4156b_readData	eod,data_type,value,status,channel

A program example is shown in Figure 3-28 on page 3-33. This program measures bipolar transistor collector current and base current. The measurement setup is shown in Figure 3-27.

Figure 3-27





Table 3-17Program Explanation

Object Title	Menu	Explanation
Channels,Ch1,Ch2, Ch1Mode,Ch2Mode, Ch1Range,Ch2Range	Data-Constant-Integer Data-Constant-Real	Enters data to allocate array, and array element for channel[], mode[], range[] of hp4156b_startMeasure.
A+1	Device-Formula	Calculates A+1 to allocate array.
AllocReal, AllocInteger	Data-AllocateArray-Real Data-AllocateArray-Integer	Allocates array for channel, mode, range of hp4156b_startMeasure.
a[0]=b, a[1]=b	Data-AccessArray-SetValues	Sets data of array (array element).
For Count	Flow-Repeat-ForCount	Repeats next action for specified count.
To/From HP4156B	I/O-InstrumentManager-Plug&play	Executes measurement or reads data.
Shift Register	Device-ShiftRegister	Outputs last data and 1 prev data.
Ic, Ib	Display-AlphaNumeric	Displays Ic and Ib.

3-33

Pulsed Sweep Measurements

To make pulsed sweep measurements, use the following functions.

Table 3-18 Functions for Pulsed Sweep Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state (pulse channel must be set to OFF)
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Sweep Source Setup	hp4156b_setPiv	channel,mode,range,base,start,stop,point,hold, width,period,compliance
Executes measurement	hp4156b_sweepPiv	channel,mode,range,point,source[],value[], status[]
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-30 on page 3-35. This program measures MOSFET Id-Vd characteristics. The measurement setup is shown in Figure 3-29.

Figure 3-29





Figure 3-30 Program Example of Pulsed Sweep Measurement

Table 3-19

Program Explanation

Object Title	Menu	Explanation
Vs,Vg,Vsub VdStart,VdStop MeasPoints	Data-Constant-Real Data-Constant-Integer	Enters input parameters of hp4156b_force, hp4156b_setPiv, and hp4156b_sweepPiv.
To/From HP4156B	I/O-InstrumentManager- Plug&play	Executes measurement.
AllocReal	Data-AllocateArray-Real	Allocates array for Vd[],Id[],status[] of hp4156b_sweepIv.
Status Code	Display-AlphaNumeric	Displays status[].
Id-Vd Curve	Display-XvsYPlot	Plots Id-Vd curve.

Multi-Channel Pulsed Sweep Measurements

To make multi-channel pulsed sweep measurements, use the following functions.

 Table 3-20
 Functions for Multi-Channel Pulsed Sweep Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state (pulse channel must be set to OFF)
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Sends Command String	hp4156b_cmd	command (PT and PWV commands are sent)
Executes measurement	hp4156b_startMeasure	meas_type,channel[],mode[],range[],source
Disables output	hp4156b_zeroOutput	channel
Reads measurement data	hp4156b_readData	eod,data_type,value,status,channel

A program example is shown in Figure 3-32 on page 3-37. This program measures bipolar transistor Ic, Ib-Vbe characteristics. The example uses the User Function of the HP VEE. See Figure 3-33 on page 3-38. The measurement setup is shown in Figure 3-31.

Figure 3-31







Table 3-21Program Explanation

Object Title	Menu	Explanation
VbeStart,VbeStop MeasPoints	Data-Constant-Real Data-Constant-Integer	Enters PWV command parameters.
For Count	Flow-Repeat-ForCount	Repeats next action for specified count.
To/From HP4156B	I/O-InstrumentManager-Plug&play	Executes measurement, or reads data.
ABS(A)	Device-Formula	Calculates absolute value of Vbe (source).
Ic,Ib-Vbe	Display-XvsYPlot	Plots Ic-Vbe and Ib-Vbe curves.

Programming Examples Using HP VEE Multi-Channel Pulsed Sweep Measurements





Table 3-22Program Explanation

Object Title	Menu	Explanation
Channels,Ch1,Ch2, Ch1Mode,Ch2Mode, Ch1Range,Ch2Range	Data-Constant-Integer Data-Constant-Real	Enters data to allocate array, and array element for channel[], mode[], range[] of hp4156b_startMeasure.
A+1	Device-Formula	Calculates A+1 to allocate array.
AllocReal, AllocInteger	Data-AllocateArray-Real Data-AllocateArray-Integer	Allocates array for channel, mode, range, of hp4156b_startMeasure.
a[0]=b, a[1]=b	Data-AccessArray-SetValues	Sets data of array (array element).
Text	Data-Constant-Text	Enters PWV command parameters.
A+B	Device-Formula	Calculates A+B to create PWV command.

Staircase Sweep with Pulsed Bias Measurements

For staircase sweep with pulsed bias measurements, use the following functions.

Table 3-23 Functions for Staircase Sweep with Pulsed Bias Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state (pulse channel must be set to OFF)
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance,polarity
Forces pulse bias	hp4156b_setPbias	channel,mode,range,base,peak,width,period, hold,compliance
Sweep Source Setup	hp4156b_setIv	channel,mode,range,start,stop,point,hold,delay, s_delay,comp,p_comp
Executes measurement	hp4156b_sweepPbias	channel,mode,range,point,source[],value[], status[]
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-35 on page 3-40. This program measures bipolar transistor Ic-Vc characteristics. The measurement setup is shown in Figure 3-34.

Figure 3-34 Device Connection and Source Setup for Example Program



Programming Examples Using HP VEE Staircase Sweep with Pulsed Bias Measurements



Table 3-24	Program	Explanation
		1

Object Title	Menu	Explanation
VcStart, VcStop Vb,Ve,MeasPoints	Data-Constant-Real Data-Constant-Integer	Enters input parameters of hp4156b_force hp4156b_setPbias, and hp4156b_setIv.
To/From HP4156B	I/O-InstrumentManager- Plug&play	Executes measurement.
AllocReal	Data-AllocateArray-Real	Allocates array for Vc[],Ic[],status[] of hp4156b_sweepPbias.
MeasPoints	Display-AlphaNumeric	Displays number of measurement points.
Status	Display-AlphaNumeric	Displays status[].
Ic-Vc Curve	Display-XvsYPlot	Plots Ic-Vc curve.

Sampling Measurements

To make sampling measurements, use the following functions.

Table 3-25Functions for Sampling Measurements

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
Output Filter Setup	hp4156b_setFilter	channel,state
Integration Time Setup	hp4156b_setInteg	table,time,average
Forces dc bias	hp4156b_force	channel,mode,range,value, compliance,polarity
Sampling timing setup	hp4156b_setSample	hold,interval,point
Sampling dc source setup	hp4156b_addSampleSyncIv	channel,mode,range,base,bias, compliance
Sampling pulse source setup	hp4156b_addSampleSyncPulse	channel,base,peak,count,period, width,delay,rise,fall
Executes measurement	hp4156b_sample	channel[],mode[],range[],point, index[],value[],status[]
Clears sampling source setup	hp4156b_clearSampleSync	
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-37. This program measures resistance. The example uses the User function of the HP VEE. See Figure 3-38 on page 3-43 and Figure 3-39 on page 3-44. The measurement setup is shown in Figure 3-36.

Figure 3-36







Table 3-26

Program Explanation

Object Title	Menu	Explanation
Interval,Bias, MeasCh1,MeasCh2 MeasMode, MeasRange, MeasPoints	Data-Constant-Integer, Data-Constant-Real	Enters input parameters of hp4156b_force, hp4156b_setSample, hp4156b_addSampleSyncIv, hp4156b_addSampleSyncPulse, hp4156b_sample
To/From HP4156B	I/O-InstrumentManager-Plug&play	Executes measurement.
A*B	Device-Formula	Calculates A*B to get Time value (X).
A/B	Device-Formula	Calculates A/B to get R1, R2 value (Y).
R-time	Display-XvsYPlot	Plots R-t curves.

3-42 Agilent 4155B/4156B VXIplug&play Driver User's Guide, Edition 4



Figure 3-38 SetArray User Function

Table 3-27Program Explanation

Object Title	Menu	Explanation
AllocReal, AllocInteger	Data-AllocateArray-Real Data-AllocateArray-Integer	Allocates array for channel, mode, range, index, value, status of hp4156b_sample.
a[0]=b, a[1]=b	Data-AccessArray-SetValues	Sets data of array (array element).

Programming Examples Using HP VEE Sampling Measurements





Table 3-28Program Explanation

Object Title	Menu	Explanation
GetValues	Data-AccessArray-GetValues	Gets data from array (value[],status[]).

Stress Force

For stress force, use the following functions.

Table 3-29Functions for Stress Force

Description	Function	Parameters
Output Switch Setup	hp4156b_setSwitch	channel,state
PGU output impedance setup	hp4156b_setPguR	channel,state
Forces dc bias	hp4156b_force	channel,mode,range,value,compliance, polarity
Stress timing setup	hp4156b_setStress	hold,mode,duration,period
dc stress setup	hp4156b_addStressSyncIv	source,channel,mode,range,base,stress, compliance
Pulse stress setup	hp4156b_addStressSyncPulse	source,channel,base,stress,width,delay, rise,fall
Forces stress	hp4156b_stress	status
Clears stress source setup	hp4156b_clearStressSync	
Disables output	hp4156b_zeroOutput	channel

A program example is shown in Figure 3-41 on page 3-46. This program forces dc stress and pulse stress to the DUTs (device under test). The measurement setup is shown in Figure 3-40.

Figure 3-40 Device Connection and Source Setup for Example Program



Programming Examples Using HP VEE Stress Force



Object Title	Menu	Explanation
Vsub,hold,Count, period,DCVstress, Pulsestress,width, delay,rise,fall	Data-Constant-Real Data-Constant-Integer	Enters input parameters of hp4156b_force, hp4156b_setStress, hp4156b_addStressSyncIv, hp4156b_addStressSyncPulse, hp4156b_stress.
To/From HP4156B	I/O-InstrumentManager-Plug&play	Forces dc stress and pulse stress.
Status,ErrorCode, ErrorMessage	Display-AlphaNumeric	Displays measurement status, error code, error message. Ignore status code 64 which is meaningless as response of hp4156b_stress.

4 Sample Application Programs for HP VEE

This chapter explains how to use the sample application programs stored on the HP VEE Sample Program Disk furnished with Agilent 4155B/4156B. This chapter consists of the following sections:

- "Introduction"
- "Installation"
- "Using sample1.vee"
- "Using sample2.vee"
- "Customizing Sample Programs"

CAUTION

The program and setup files stored on the Sample Program Disk are examples only, and may need to be customized for your specific application. Agilent Technologies is not responsible for any damage that may occur from the use of these sample programs.

NOTE Copy the HP VEE Sample Program Disk, and keep the original disk as a backup. To store a program after modifying it, use a file name that is different than the original program name.

Introduction

This section introduces the sample application programs for HP VEE that are furnished with the 4155B/4156B, and covers the following sections:

- "HP VEE Sample Program Disk"
- "What are Sample Programs?"

HP VEE Sample Program Disk

The HP VEE Sample Program Disk stores sample application programs using HP VEE and VXI*plug&play* drivers for the 4155B/4156B and the E5250A. The sample programs can control the 4155B/4156B, Agilent E5250A low leakage switch mainframe, and the Summit series semi-auto prober from Cascade Microtech, Inc.

The following files are stored on the disk.

readme.txt

This is a text file with a brief introduction of the sample programs, installation information, and so on.

• sample1.vee and sample2.vee

These are program files that are executable on HP VEE version 4.0 or later. Refer to "What are Sample Programs?".

• sample.ppd

This file is an example of data used to control the Summit series semi-auto prober from Cascade Microtech, Inc. The *.ppd files will be created and used by the prober control software (PCS) furnished with the prober or supplied from Cascade Microtech, Inc. The sample application programs require the *.ppd file and PCS to control the prober.

What are Sample Programs?

The Sample Program Disk stores two program files, sample1.vee and sample2.vee. Both programs control the 4155B/4156B, E5250A low leakage switch mainframe, and Cascade Summit series semi-auto prober, and do the following:

- 1. Probe two MOSFETs on a die
- 2. Measure Id-Vg characteristics of two MOSFETs
- 3. Extract the threshold voltage (Vth value) for two MOSFETs
- 4. Store the measured data into files, and display the results

The differences between the two programs are the probing control and the display, as shown in Table 4-1.

	sample1.vee	sample2.vee
Probing Control	Step-by-step Measurement. Probes the die where you specified the die position (x-y index) defined in the *.ppd file.	Sequential Measurement. Probes sequentially for the dies defined in the *.ppd file.
Display	Vth value, Vth pass/fail status on Wafer Map, X-Y (Vg-Id) Graph of device 1, X-Y (Vg-Id) Graph of device 2	Vth value, Vth pass/fail status on Wafer Map, Histogram of Vth value, X-Y (Vg-Id) Graph of the specified device

Table 4-1Differences Between sample1.vee and sample2.vee
Definition of Vth

The threshold voltage (Vth) is extracted by a linear interpolation using two measurement points, which are the nearest from the targeted point for both higher and lower directions. The targeted point (Vg_extract,Id_target) is an ideal point, which indicates the Id_target value on the line through the two measurement points on the Id-Vg curve. See Figure 4-1.





Execution Mode

The sample1.vee and sample2.vee programs have five execution modes, as described below. The default is Offline mode.

NOTE If you do not use the Cascade Summit series semi-auto prober, use sample1.vee with Online mode, standalone, or with the E5250A. The sample2.vee program is used for sequential test, using the semi-auto prober. The test results for sample2.vee will be meaningless in the Online mode without the prober.

Offline mode

Select this mode if you do not use an instrument. After program execution, the demo (dummy) data is returned as the test result.

• Online mode, standalone (4155B/4156B only)

Select this mode if you use the 4155B/4156B only. The test device is a single MOSFET, as the 4155B/4156B has four SMUs to connect and measure a 4-terminal device simultaneously. A test fixture or manual prober is required to connect the device.

• Online mode with E5250A

Select this mode if you use the 4155B/4156B and E5250A. A test fixture or manual prober is required to connect the devices.

• Online mode with semi-auto prober

Select this mode if you use the 4155B/4156B and the Cascade Microtech Summit series semi-auto prober. The test device is a single MOSFET, as the 4155B/4156B has four SMUs to connect and measure a 4-terminal device simultaneously.

• Online mode, fully automatic

Select this mode if you use the 4155B/4156B, E5250A, and the Cascade Summit series semi-auto prober.

NOTE The sample programs require that the E5250A be installed with two E5252A matrix cards. They must be installed in slots 1 and 2 of the E5250A mainframe.

Measurement Connection and Source Setup

Figure 4-2 shows the measurement connection for instruments, the prober and devices. This setup is for the fully automatic Online mode. For other modes, ignore the equipment not used. This figure also shows the default source setup.

Figure 4-2 Measurement Connection and Source Setup



NOTE

To avoid misconnection, pay close attention to the die (device1 and device2) and the pin assignment of the probe card, if used.

NOTE In Figure 4-2, OUT 1 to 9 indicates output port 1 to 9 of the matrix card installed in slot 1 of the E5250A; OUT 23 indicates output port 11 of the card installed in slot 2 of the E5250A.

Sample Application Programs for HP VEE Introduction

Measurement Data Files

The sample programs create three types of data files, as shown below.

info.txt	Information file. Title, date, and comment are included.
vth <i>n</i> .txt	Vth data file. If 5 dies are tested, 5 data are included. For the file name, n is 1 or 2 (1 for device1, 2 for device2).
d <i>n</i> vgidxy.txt	Row measurement data file of Id-Vg curve. If 5 dies are tested, the program creates 10 data files (5 files/device). The file names n, x , and y indicate the following:
	<i>n</i> : 1 or 2 (1 for device1, 2 for device2).
	<i>x</i> : X-index of the die position.
	<i>y</i> : Y-index of the die position.

Figure 4-3 Example of Data Files Created by Sample Programs

info.txt

Data Save Directory for HP4155B/4156B Sample Program Mon 15/Jun/1998 14:14:30 Comment :

vth1.txt

Device 1 Vth Table X Index Y Index 7 5 5 5 3 5 5 3 5 3	"Vth [V]" 9.21E-01 9.19E-01 7.32E-01 9.20E-01 9.22E-01
--	---

vth2.txt

Device 2 Vth Table X Index Y Inc 5 5 5 5 3 5 5 3 5 3	ex "Vth [V]" 9.10E-01 9.19E-01 9.06E-01 9.22E-01 9.09E-01
--	--

1 Vg-Id Data Id [A] 8.00E-15 8.00E-15 6.06E-15 6.00E-15 6.00E-15 5.06E-15 5.06E-15 2.87E-14 4.61E-13 9.17E-12 2.91E-09	Id 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Status

d2vgid55.txt

dlvgid55.txt

(5,5) Device Vg [V] -5.00E-01 -4.13E-01 -3.25E-01 -2.38E-01 -6.25E-02 2.50E-02 1.13E-01 2.00E-01 2.88E-01 3.75E-01 4.63E-01 5.50E-01	<pre>2 Vg-Id Da Id [A] 9.00E-15 8.00E-15 8.00E-15 8.00E-15 6.00E-15 6.00E-15 6.00E-15 6.00E-15 5.00E-15 5.00E-15 2.99E-14 4.85E-13 9.67E-12</pre>	ta Id Sta 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	tus
		_	_

Installation

This section explains the equipment and accessories required to use the sample programs, and how to install the programs.

Required Equipment and Accessories

1. PC (AT-compatible) for Windows

HP VEE (version 4.0 or later) and the VXI*plug&play* drivers for the 4155B/4156B and E5250A must be installed in your PC and ready for use. See Chapter 1.

A 3.5 inch flexible disk drive must be connected to your PC to install the sample programs.

If you use the Cascade Microtech Summit series semi-auto prober, the prober control software (PCS) supplied by Cascade Microtech, Inc. must be installed in your PC and the prober must be connected to your PC via Cascade's interface. For the interface, and the operating system supported by the PCS, contact Cascade Microtech, Inc. (PCS version 2.50 supports Windows 95 only).

- 2. HP VEE Sample Program Disk
- 3. Agilent 4155B or 4156B Semiconductor Parameter Analyzer
- 4. Agilent E5250A Low Leakage Switch Mainframe

Two E5252A matrix cards are required and must be installed in slot 1 and 2 of the E5250A.

5. Cascade Microtech Summit Series Semi-Auto Prober

If you do not use the semi-auto prober, prepare the manual prober or test fixture, such as Agilent 16442A, to connect the test devices.

6. Connection Cables

Four triaxial cables are required to connect the 4155B/4156B and E5250A.

Eight triaxial cables are required to connect the E5250A and the prober or test fixture. You will also need coaxial cables, probe card, manipulators, or wire to connect the test devices.

Two GPIB cables are required to connect the instruments and the PC.

Installing the Sample Programs

- 1. Make a working directory where you can install and execute the sample programs, using Windows Explorer.
- 2. Create a subdirectory in the working directory. The subdirectory will be used to save the measurement data files.
- 3. Insert the HP VEE Sample Program Disk into the flexible disk drive connected to your PC.
- 4. Copy all of the files on the disk to the working directory.



Using sample1.vee

This section covers the following topics.

- "Program Execution Flow"
- "Panel Display"
- "To Execute sample1.vee"

NOTE For the wafer test using the Summit series semi-auto prober from Cascade Microtech, Inc., create your own probe plan file (*.ppd). The sample.ppd file stored on the HP VEE Sample Program Disk is an example only.

Program Execution Flow

The execution flow of the sample1.vee program is shown in Figure 4-5 and Table 4-2.

Figure 4-5 Execution Flow of sample1.vee



	Object	Explanation
1	H/W Configuration	Defines execution mode. Set the mode before running sample1.vee.
2	Save Directory, Init G data dir	Defines name of the subdirectory to save the measurement result data. See "Installing the Sample Programs" on page 10.
3	Save Info File	Defines and saves the information file (info.txt) which contains title, date, and comments for the subdirectory. You can enter comments. See "Measurement Data Files" on page 8.
4	Init Prober	Initializes Cascade Summit series semi-auto prober, if used.
5	Init Instrument	Initializes instrument, if used.
6	1, Init G 1st meas	Sets G_1st_meas value. If G_1st_meas=1, header lines are written in vth1.txt and vth2.txt. See "Measurement Data Files" on page 8.
7	Until Break	Repeats the following sequence until a break occurs.
8	Start Measurement	Triggers the start of the measurement.
9	X Index, Init G xidx, Y Index, Init G yidx	Defines X and Y index of the die tested. The index must be defined in the *.ppd file used.
10	Goto Next Die, Break	Probes the die specified by the X-Y index. Breaks if X index < 0 .
11	Device1 Vth Measurement Device2 Vth Measurement	Executes Id-Vg measurement, extracts Vth, and saves measurement results. See "Measurement Data Files" on page 8.
12	Device1 Vg-Id Graph Device2 Vg-Id Graph	Displays Id-Vg measurement result graphs of Device 1 and 2. See Figure 4-6.
13	Show Result	Displays Vth value and wafer map. See Figure 4-6. Dev1 Vth and Dev2 Vth show Vth value, and the field below shows wafer map.
14	Update G 1st meas	Sets G_1st_meas variable to 0.
15	Reset Instrument	Resets the instruments.
16	Reset Prober	Resets the prober.

Table 4-2Execution Flow of sample1.vee

Sample Application Programs for HP VEE Using sample1.vee

Panel Display

The sample1.vee program displays the following data and graph. See Figure 4-6.

Vth	Displays Vth value of device 1 and 2. The data is in volts.
Vg-Id Graph	Displays Id-Vg curve of device 1 and 2.
X, Y Index	Displays wafer map of Vth value using the following characters.
	.: Both device 1 and 2 test data are within the allowable range.
	F1: Device 1 test data is out of the allowable range.
	F2: Device 2 test data is out of the allowable range.
	F3: Both device 1 and 2 test data are out of the allowable range.
	The allowable range is specified by Dev1(2) Vth Min and Dev1(2) Vth Max input fields. Min field sets the lower limit, and Max field sets the upper limit.





To Execute sample1.vee

Before executing the sample1.vee program, do the following.

NOTE	If you execute sample1.vee in Of	fline mode, skip	steps 1 through :	5.		
	1. Connect GPIB cables betwee	n your PC and th	ie instruments be	ing used.		
	Confirm that the semi-auto printerface, or connect the prob	rober is connecte per to your PC, if	ed to your PC via used.	Cascade's		
	 Connect the measurement cal fixture being used. See "Measurement" 	bles between the surement Conne	instruments and ction and Source	the prober or test Setup" on page 7.		
	4. Turn on the instruments and t	the semi-auto pro	ober being used, i	if applicable.		
	5. Display the SYSTEM: MISC NOT SYSTEM CONTROLL	ELLANEOUS s LER in the 4155E	creen on the 4155 3/ <i>4156B is</i> field.	5B/4156B. Select		
	 Run HP VEE. If this is the first time using HP VEE and VXI<i>plug&play</i> drivers for the 4155B/4156B and E5250A, register the drivers at this time. See "Programming Basic" in Chapter 3. 					
	7. Open the sample1.vee progra	7. Open the sample1.vee program.				
	 Display the program (Figure 4-5) and double click the H/W Configuration object. The panel of this object is displayed. 					
	9. On the panel, select the check button of the instruments being used and the semi-auto prober, if used. See Table 4-3.					
Table 4-3	H/W Configuration Object Check Button Setup					
	Execution Mode	4155/56B	E5250A	Semi-Auto Prober		
	Online, standalone	check				
	Online, with E5250A	check	check			
	Online, with prober	check		check		
	Online, fully automatic	check	check	check		
	Offline	-	-			

Sample Application Programs for HP VEE Using sample1.vee

	То	execute the sample1.	vee program, do the following.
NOTE	Ify	ou execute sample1.	vee in Offline mode, skip steps 3, 5, and 6.
	1.	Create a directory (E measurement data. 7 the Sample Program	Example: C:\lot1\test1\data) to be used to save the To create a directory, use Windows Explorer. See "Installing s" on page 10.
	2.	Display the panel (F	igure 4-6) and enter the following input fields.
		Save Directory	Enter the name of the directory to save measurement data. Enter only the name if the directory is under the current directory which this program is stored, or enter the entire path to specify another directory, such as C:\lot1\test1\data.
		Load PPD File	Enter the file name of the probe plan data file (*.ppd) for the Cascade Microtech Prober Control Software. Ignore this field if you do not use the semi-auto prober.
		Dev1 Vth Min/Max	Enter the allowable range of device 1 Vth value. Min field sets the lower limit, Max field sets the upper limit.
		Dev2 Vth Min/Max	Enter the allowable range of device 2 Vth value. Min field sets the lower limit, Max field sets the upper limit.
	3.	Connect the device.	
		If you use the semi-a handle up.	auto prober, load a wafer on the prober, and keep the platen
		If you do not use the fixture, or load a wa	semi-auto prober, connect devices (two MOSFETs) to a test fer on a manual prober and probe a die tested.
	4.	Click the run button the Wait the DDE Se Microtech prober co	on the HP VEE menu bar. If you use the semi-auto prober, erver setup dialog box is displayed, and the Cascade ntrol software is called. See Figure 4-7
		If you do not use the	e semi-auto prober, skip steps 5 and 6.
	5.	Click Continue. A w in Figure 4-8.	indow for the prober control software is displayed as shown
		This example shows The title of the wind input field in step 2.	the SAMPLE.PPD window of the prober control software. ow will be the file name you entered in the Load PPD File
	6.	Move the wafer to a click OK in the ALI	lign the probes over the probe plan alignment position, then GN PROBES dialog box.

Figure 4-7	Running sample1.vee v Professional Sample Professional Sample Profess	vith Cascade Microtech Pr Wndow Heb Wndow	Coher Control Software (1)
	Kangara ang kang kang kang kang kang kang kang		Units of measure Microns Summit 12000 +SEPARATE 0 0 0





Sample Application Programs for HP VEE Using sample1.vee

- 7. Enter the X-Y index of the die to be tested in the X Index and Y Index input fields. Only the index defined in the *ppd file is effective for this test.
- 8. Click Start Measurement. The program executes the Id-Vg measurement, extracts Vth value, displays the results, and stores the data into files. The program then waits for your input.

Figure 4-9 Execution Example of sample1.vee



- 9. Repeat steps 7 and 8 for all dies to be tested.
- 10. To stop the program, click the stop button on the HP VEE menu bar.
- **NOTE** In Offline mode, the program returns the dummy data instead of the raw measurement data in step 8.

NOTEA wafer map is also displayed in the Cascade Microtech Prober Control Software
*.ppd window. This window indicates results by using the following color scheme.

- Green: Both device 1 and 2 test data are within the allowable range.
- Yellow: Device 1 test data is out of the allowable range.
- Magenta: Device 2 test data is out of the allowable range.
- Red: Both device 1 and 2 test data are out of the allowable range.

NOTE To exit the Cascade Microtech prober control software, select the File-Exit menu of the Cascade Microtech DDE Server window, then click Yes in the Halt Cascade DDE Server dialog box.

Using sample2.vee

This section covers the following topics.

- "Program Execution Flow"
- "Panel Display"
- "To Execute sample2.vee"

NOTE For the wafer test using the Summit series semi-auto prober from Cascade Microtech, Inc., create your probe plan file (*.ppd). The sample.ppd file stored on the HP VEE Sample Program Disk is an example only.

Sample Application Programs for HP VEE Using sample2.vee

Program Execution Flow

The execution flow of the sample2.vee program is shown in Figure 4-10 and Table 4-4.

Figure 4-10 Execution Flow of sample2.vee



	Object	Explanation
1	Until Break	Repeats the following sequence until a break occurs.
2	Start Measurement	Triggers the start of the wafer test.
3	H/W Configuration	Defines execution mode. Set the mode before running sample2.vee.
4	Save Directory, Init G data dir	Defines name of the subdirectory to save measurement result data. See "Installing the Sample Programs" on page 10.
6	Save Info File	Defines and saves the information file (info.txt) which contains title, date, and comments for the subdirectory. You can enter comments. See "Measurement Data Files" on page 8.
7	Init Prober	Initializes Cascade Summit series semi-auto prober, if used.
8	Init Instrument	Initializes instruments, if used.
9	1, Init G 1st meas	Sets G_1st_meas value. If G_1st_meas=1, the prober sets the first die to probe, and header lines are written in vth1.txt and vth2.txt. See "Measurement Data Files" on page 8.
10	Goto Next Die, Break	Probes the die to test. The die and probing sequence depend on the *.ppd file used. Breaks if the test was completed for all die.
11	Get G xidx, Get G yidx Current X, Y Index	Gets and displays the X-Y index of the die now tested.
13	Device1 Vth Measurement Device2 Vth Measurement	Executes Id-Vg measurement, extracts Vth, and saves measurement results. See "Measurement Data Files" on page 8.
14	Show Result	Displays Vth value and wafer map. See Figure 4-11. Dev1 Vth and Dev2 Vth show Vth value, and the field below shows wafer map.
15	Update G 1st meas	Sets G_1st_meas variable to 0.
16	Reset Instrument	Resets the instruments.
17	Reset Prober	Resets the prober.
	View Vg-Id Graph	Displays Id-Vg curve of the device you select.
	View Vth Histogram	Displays histogram for Vth of the device you select (device 1 or device 2).

Table 4-4Execution Flow of sample2.vee

Sample Application Programs for HP VEE Using sample2.vee

Panel Display

The sample2.vee program displays the following data and graph. See Figure 4-11.

Vth	Displays Vth value of device 1 and 2. The data is in volts.	
Histogram	Displays histogram of Vth value for the device selected. Enter the file name, then click View to display the histogram.	
Vg-Id Graph	Displays Id-Vg curve for the device selected. Enter the file name, then click View to display the graph.	
X, Y Index	Displays wafer map of Vth value using the following characters.	
	.: Both device 1 and 2 test data are within the allowable range.	
	F1: Device 1 test data is out of the allowable range.	
	F2: Device 2 test data is out of the allowable range.	
	F3: Both device 1 and 2 test data are out of the allowable range.	
	The allowable range is specified by Dev1(2) Vth Min and Dev1(2) Vth Max input fields. Min field sets the lower limit, and Max field sets the upper limit.	

Figure 4-11 Panel Display of sample2.vee



To Execute sample2.vee

Before executing the sample2.vee program, do the following.

NOTE	If you execute sample2.vee in Offline mode, skip steps 1 through 5.						
	1. Connect the GPIB cables between your PC and the instruments being used.						
	 Confirm that the semi-auto prober is connected to your PC via Cascade's interface, or connect the prober to your PC, if used. 						
	3. Connect the measurement cables between the instruments and the prober or test fixture used. See "Measurement Connection and Source Setup" on page 7.						
	4. Turn on the instruments and the semi-auto prober being used, if applicable.						
	 Display the SYSTEM: MISCELLANEOUS screen on the 4155B/4156B. Then select NOT SYSTEM CONTROLLER in the 4155B/4156B is field. 						
	6. Run HP VEE. If this is the first time using HP VEE and VXI <i>plug&play</i> drivers for the 4155B/4156B and E5250A, register the drivers at this time. See "Programming Basic" in Chapter 3.						
	7. Open the sample2.vee program.						
	 Display the program (Figure 4-10) and double click the H/W Configuration object. The panel for the object is displayed. 						
	9. On the panel, select the check button of the instruments and the semi-auto prober being used, if applicable. See Table 4-5.						
Table 4-5	H/W Configuration Object Check Button Setup						
	Execution Mode	4155/56B	E5250A	Semi-Auto Prober			
	Online, standalone	check					
	Online, with E5250A	check	check				
	Online, with prober	check		check			
	Online, fully automatic	check	check	check			
	Offline						

Sample Application Programs for HP VEE Using sample2.vee

	To execute the sample2.vee program, do the following.				
NOTE	If you execute sample2.vee in Offline mode, skip steps 4, 6, and 7.				
	1. Click the run button on the HP VEE menu bar.				
	 Create a directory (Example: C:\lot1\test1\data) to save the measurement data. To create a directory, use Windows Explorer. See "Installing the Sample Programs" on page 10. 				
	3. Enter the following input fields.				
	Save Directory Enter the name of the directory to save measurement data. Enter only the name if the directory is under the current directory where this program is stored, or enter the entire path to specify a different directory, such as C:\lot1\test1\data.				
	Load PPD File Enter the file name of the probe plan data (*.ppd) file for Cascade Microtech Prober Control Software. Ignore this field if the semi-auto prober is not used.				
	Dev1 Vth Min/Max Enter the allowable range of Vth value for device 1. Min field sets the lower limit, Max field sets the upper limit.				
	Dev2 Vth Min/Max Enter the allowable range of Vth value for device 2. Min field sets the lower limit, Max field sets the upper limit.				
	4. Connect the device.				
	If you use the semi-auto prober, load a wafer on the prober, and keep the plater handle up.				
	If you do not use the semi-auto prober, connect devices (two MOSFETs) to a tes fixture, or load a wafer on a manual prober and probe a die tested.				
	 Click Start Measurement. If you use the semi-auto prober, the Wait the DDE Server setup dialog box is displayed, and the Cascade Microtech prober contro software is called. See Figure 4-12 				
	If you do not use the semi-auto prober, skip steps 6 and 7.				
	 Click Continue. A window of the prober control software is displayed as shown in Figure 4-13. 				
	This example shows the SAMPLE.PPD window of the prober control software The title of the window will be the file name you entered in the Load PPD File input field in step 3.				



Figure 4-12 Running sample2.vee with Cascade Microtech Prober Control Software (1)

Figure 4-13

Running sample2.vee with Cascade Microtech Prober Control Software (2)



Sample Application Programs for HP VEE Using sample2.vee

- 7. Move the wafer to align the probes over the probe plan alignment position, then click OK in the ALIGN PROBES dialog box.
- 8. Wait until wafer test is completed. The program executes the Id-Vg measurement, extracts Vth value, displays the results, and stores the data into files. The program then waits for your input.

Figure 4-14Execution Example of sample2.vee



9. Repeat step 2 through 8 for all wafers to be tested.

10. To stop the program, click the stop button on the HP VEE menu bar.

NOTE	In Offline mode, the program returns the dummy data instead of the raw measurement data in step 8.		
NOTE	A wafer map is also displayed in the Cascade Microtech Prober Control Software *.ppd window. The window indicates the results by using the following color scheme.		
	Green:	Both device 1 and 2 test data are within the allowable range.	
	Yellow:	Device 1 test data is out of the allowable range.	
	Magenta:	Device 2 test data is out of the allowable range.	
	Red:	Both device 1 and 2 test data are out of the allowable range.	
NOTE	To exit the Cascade Microtech Prober Control Software, select the File-Exit menu of the Cascade Microtech DDE Server window. Then click Yes in the Halt Cascade DDE Server dialog box.		

Customizing Sample Programs

This section offers examples of modifications to the sample1.vee and sample2.vee programs:

- "To Change an GPIB Address"
- "To Change the Vth Measurement Setup"
- "To Remove a Test Device"
- "To Remove a Source Output"
- "To Add a Test Device"
- "To Add a Measurement Parameter"

To Change an GPIB Address

You can change the GPIB address of the 4155B/4156B and E5250A by using the HP VEE Instrument Manager.

- 1. Select the I/O-InstrumentManager menu from the HP VEE menu bar. The Instrument Manager dialog box is displayed.
- 2. Select the instrument (Example: HP4156B) from the Instrument Manager dialog box, and then click Edit. The Device Configuration dialog box is displayed.
- 3. Enter the new address in the Address field. For example, enter "717".
- 4. Click Advanced I/O Config. The Advanced Device Configuration dialog box is displayed.
- 5. Select the Plug&play Driver Tab, and then enter the new address in the Address field. For example, enter "GPIB0::17::INSTR".
- 6. Click OK in the Advanced Device Configuration dialog box.
- 7. Click OK in the Device Configuration dialog box.
- 8. Click Save Config in the Instrument Manager dialog box to register the new address.



Figure 4-15 To Change an GPIB Address

To Change the Vth Measurement Setup

You can change the 4155B/4156B source setup and the E5250A switching setup by editing the Device 1 (or 2) Vth Measurement object. See Figure 4-16.

- 1. Open the sample1.vee or sample2.vee program.
- 2. Double click Device 1 (or 2) Vth Measurement in the HP VEE program explorer. The Device 1 (or 2) Vth Measurement object is displayed.
- 3. Change the Device ID for MOSFET if needed, using a string format.
- 4. Change the setup for all terminals for MOSFET.

Pin	E5250A output channel number; 1 to 24 are available.
SMU Ch	4155B/4156B SMU number; 1 to 4 are available.
Voltage	SMU output voltage (in volts).
Start, Stop Voltage	SMU output voltage for Vg sweep (in volts).

- 5. Change the target Id for extracting Vth. See "Definition of Vth" on page 5.
- 6. Change the number of measurement points in a sweep; 2 to 256 are available.

Figure 4-16 Vth Measurement Panel Display



Sample Application Programs for HP VEE Customizing Sample Programs
If you want to change other source setup parameters, such as compliance, you will need to change the setup of the To/From object, by doing the following.
Display the program for the Device 1 (or 2) Vth Measurement object.
Open the Vth Measurement object, and display the program.
Open the Pre-Setup object, and then open the Setup4155 object.
Double click hp4156b_force and display the Edit Function Panel.
Change the setup value on the panel.

To Remove a Test Device

If your test die includes only one MOSFET, modify the program as shown below. This example modifies sample2.vee, and removes objects for device 2.

- 1. Cut the Device 2 Vth Measurement object from the Main program display.
- 2. Connect the control line between the Device 1 Vth Measurement object and the Update G 1st meas object.
- 3. Open the Show Result object using the HP VEE program explorer.



Figure 4-17 To Remove a Test Device (1)

- 4. Display the Show Result object program, and cut the following seven objects.
 - Dev2 Vth, Dev2 Vth Min, Dev2 Vth Max, If Vth Pass (for device2)
 - If/Then/Else
 - F2, F3
- 5. Delete the input terminal Vth2.
- 6. Add the Flow-If/Then/Else object, and enter A, then connect the lines:
 - between If Vth Pass and If/Then/Else A terminal
 - between If/Then/Else Then terminal and P
 - between If/Then/Else Else terminal and F1
- 7. Double click the JCT object, and delete the input terminals C and D.

Figure 4-18To Remove a Test Device (2)



To Remove a Source Output

If the number of terminals for your device is less than four, modify the program as shown below. This example modifies sample2.vee, and removes objects for the substrate terminal of device 1 (the example does not modify the objects for device 2).

- 1. Open the Vth Measurement object using the HP VEE program explorer.
- 2. Display the program, and cut the following three objects.
 - Substrate SMU Ch
 - Substrate Pin
 - Substrate Voltage
- 3. Open the Formula object, and delete the sub_ch and sub_pin input terminals.
- 4. Change the formula, defined in the Formula object, as shown below.

[drain_ch*100+drain_pin, gate_ch*100+gate_pin, source_ch*100+source_pin, 0]

Figure 4-19 To Remove a Source Output (1)



4-32 Agilent 4155B/4156B VXIplug&play Driver User's Guide, Edition 4

- 5. Open the Pre-Setup object, and delete the sub_ch and Vsub input terminals.
- 6. Open the Setup 4155 object, and delete the sub_ch and Vsub input terminals.
- 7. Delete the hp4156b_force(instrHandle,sub_ch,....) function from the Setup 4155 object.



To Add a Test Device

If your test die includes three MOSFETs, modify the program as shown below. This example modifies sample2.vee, and adds the Vth measurement and display objects for the third MOSFET.

- 1. Copy and paste the Device 2 Vth Measurement object on the Main program display, and change the title to Device 3 Vth Measurement.
- 2. Change the measurement setup, Device ID String, pin, voltage, and so on, for the third device on the panel display of the Device 3 Vth Measurement object. See "To Change the Vth Measurement Setup" on page 29.
- 3. Cut the line between the Device 2 Vth Measurement object and Update G 1st meas object, then connect the lines as shown below.
 - between Device 2 Vth Measurement and Device 3 Vth Measurement
 - between Device 3 Vth Measurement and Update G 1st meas
- 4. Open the Show Result object program display, and add the Vth3 input terminal. See Figure 4-22.
- 5. Open the If/Then/Else object, and add the t3 input terminal.



Figure 4-21To Add a Test Device (1)

- 6. Copy and paste the following four objects, and change title Dev2 to Dev3.
 - Dev2 Vth Min, Dev2 Vth Max, Dev2 Vth, and If Vth Pass
- 7. Connect the lines shown below:
 - between Vth3 terminal and Dev3 Vth object
 - between Vth3 terminal and the data input terminal of If Vth Pass object
 - between If Vth Pass and t3 input terminal of If/Then/Else object
- 8. Change the definition of the If/Then/Else object as shown in Figure 4-22.
- 9. Copy and paste P, F1, F2 and F3 objects, and change the title and entry to F4, F5, F6, and F7, respectively.
- 10. Cut the line between Else and F3, and connect lines for F3, F4, F5, F6, and F7 as shown in Figure 4-22.
- 11. Open the JCT object, create an additional four input terminals, and connect the lines for E, F, G, and H as shown in Figure 4-22.
- 12. Open the Dev3 Vth, Dev3 Vth Min, and Dev3 Vth Max objects, and select them. Then click the Add to Panel button. The objects are added to the Show Result panel display. Adjust the position and size of the objects.



Figure 4-22 To Add a Test Device (2)

- 13. Open the Main program display, and connect the line between the Vth terminal of the Dev3 Vth Measurement object and the Vth3 terminal of the Show Result object.
- 14. Click the right mouse button on the Show Result object, and select the Restore menu. The Show Result object panel display is restored on the Main program display.
- 15. Select the restored Show Result object, and click the Add to Panel button. The object is added to the Main panel display. Delete the old Show Result object, and adjust the position and size of the new Show Result object.

Figure 4-23 To Add a Test Device (3)



NOTE	The modifi result displ	cation example shown above changes the meaning of the wafer map ay as shown below.
	Р	Test results of all devices are within the allowable range.
	F1	Device 1 test result is out of the allowable range.
	F2	Device 2 test result is out of the allowable range.
	F3	Device 3 test result is out of the allowable range.
	F4	Test results of device 1 and 2 are out of the allowable range.
	F5	Test results of device 2 and 3 are out of the allowable range.
	F6	Test results of device 1 and 3 are out of the allowable range.
	F7	Test results of all devices are out of the allowable range.

To Add a Measurement Parameter

If you want to add a measurement parameter, such as drain current Id, modify the program as shown below. This example modifies sample2.vee for device 1 only (this example does not modify the objects for device 2).

- Adds the measurement function to the Measurement object.
- Adds the object to set the dummy data to the Meas 4155 (Offline) object.
- Adds the object to set the measurement source to the Vth Measurement object.
- Adds the object to save the measured data to the Device 1 Measurement object.
- Modifies the Show Result object and the Main panel display.

Figure 4-24 Id Measurement Setup



To Add the Measurement Function and Dummy Data

- 1. Open the Measurement object using the HP VEE program explorer.
- 2. Create the Vg_spot input terminal in the Measurement object as shown in Figure 4-25.
- 3. Open the Meas 4155 object, and add the following three functions. Then set the parameters shown using the Edit Function Panel of each function.
 - hp4156b_opc_Q function
 - hp4156b_force function
 - a. channel : Use gate_ch variable.
 - b. mode : VOLTAGE OUTPUT
 - c. range: 0
 - d. value : Use Vg variable, and create Vg input terminal.
 - e. comp:1m
 - f. polarity : AUTO
 - hp4156b_spotMeas function
 - a. channel : Use drain_ch variable.
 - b. mode : CURRENT MEASUREMENT
 - c. range : 0
 - d. value : Use spot_id variable, and create spot_id output terminal.
 - e. status : Use spot_id_s variable, and create spot_id_s output terminal.
- 4. Connect the line between the Vg_spot input terminal and the Vg input terminal of the Meas 4155 object.
- 5. Add two Flow-Junction (JCT) objects.
- 6. Create the spot_id and spot_id_s output terminals in the Measurement object.
- 7. Connect the lines from the spot_id terminal of the Meas 4155 object to the spot_id terminal of the Measurement object via the JCT object.

Then connect the lines from the spot_id_s terminal of the Meas 4155 object to the spot_id_s terminal of the Measurement object via the JCT object.

8. Open the Meas 4155 (Offline) object.

- 9. Add the Data-Constant-Real and Data-Constant-Integer objects, and set the title to spot_id and spot_id_s, respectively. Then enter "1u" to the entry field of the spot_id object.
- 10. Create the spot_id and spot_id_s output terminals in the Meas 4155 (Offline) object.
- 11. Connect the line between the spot_id object and the spot_id terminal.

Then connect the line between the spot_id_s object and the spot_id_s terminal.

12. Connect the line between the spot_id terminal of the Meas 4155 (Offline) object and the JCT object connected to the spot_id terminal.

Then connect the line between the spot_id_s terminal of the Meas 4155 (Offline) object and the JCT object connected to the spot_id_s terminal.





To Set the Id Measurement Source

- 1. Open the Vth Measurement object program display, and change the title to Vth/Id Measurement.
- 2. Add the Data-Constant-Real object, set the title to Vg_spot, and enter any value for gate voltage in volts. This example enters 3.
- 3. Connect the line between the Vg_spot object and the Vg_spot terminal of the Measurement object.
- 4. Create the spot_id and spot_id_s output terminals in Vth/Id Measurement object.

Then connect lines between the spot_id terminal of the Measurement object and the spot_id output terminal, and between the spot_id_s terminal of the Measurement object and the spot_id_s output terminal.



Figure 4-26To Set the Id Measurement Source
To Save Measurement Data

- 1. Open the Device 1 Vth Measurement object program display, and change the title to Device 1 Measurement.
- 2. Create the spot_id and spot_id_s output terminals.
- 3. Connect the lines between the spot_id terminal of the Vth/Id Measurement object and the spot_id output terminal, and between the spot_id_s terminal of the Vth/Id Measurement object and the spot_id_s output terminal.
- 4. Copy and paste Save Vth Table, and change the title to Save Id Table.
- 5. Connect the lines between the Device Id String object and the devIdStr terminal of the Save Id Table object, and between the spot_id terminal of the Vth/Id Measurement object and the Vth terminal of the Save Id Table object.
- 6. Open the Save Id Table object panel display.
- 7. Change the characters Vth in the File Name entry field to Id.
- 8. Change the characters *Vth* in the Title entry field to *Id*.
- 9. Enter Id [A] into the Vth Label entry field.

Figure 4-27To Save Measurement Data



To Modify the Show Result and Main Panel Displays

- 1. Open the Show Result object program display.
- 2. Add the Display-Alphanumeric object, and set the title to Dev1 Id.
- 3. Create the spot_id input terminal.
- 4. Connect the line between the spot_id terminal and the Dev1 Id object.
- 5. Click the Dev Id object, then click the Add to Panel button. The Dev Id object is added to the panel display of the Show Result object. Adjust the position and size of the object.
- 6. Open the Main program display, and connect the line between the Show Result object spot_id terminal and the Device 1 Measurement object spot_id terminal.
- 7. Click the right mouse button on the Show Result object, and select Restore menu. The restored Show Result object is displayed.
- 8. Click the restored Show Result object, and click the Add to Panel button. The object is added to the Main panel display. Delete the old Show Result object from the panel, and adjust the position and size of the new Show Result object.



Figure 4-28

4-42